




Upgrade · The Home Creator Way

CHEST FREEZER

Model:BD95JEW BD95JEB BD142JEW

BD142JEB BD192JEW BD192JEB

**MODEL: BD95JEW/BD95JEB/BD142JEW/BD142JEB/BD192JEW
BD192JEB**



<Picture Only For Reference >

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

	Warning-To reduce the risk of injury, user must read instructions manual carefully.
	CORRECT DISPOSAL This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheeled bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices

Dear Consumers:

Thank you very much for purchasing our products. In order to ensure your safety and achieve the best out of this freezer, please read this instruction carefully.

- The products are commercial chest freezers. These products are intended solely for the storage and/or display of packaged products that are not potentially hazardous foods.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Please according to local regulations regarding disposal of the appliance for its flammable blowing gas. Before you scrap the appliance, please take off the doors to prevent children trapped.

- WARNING – Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- WARNING – Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer
- WARNING – Do not damage the refrigerant circuit.
- WARNING – Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance is intended to be used in household and similar applications such as, staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; Catering and similar non-retail applications.
- The appliance shall not be installed in public corridors or lobbies.
Please according to local regulations regarding disposal of the appliance for its flammable gas. Before you scrap the appliance, please take off the doors to prevent children trapped
- Warning: the appliance shall be installed in accordance with national wiring regulations
- The appliance is to be installed in accordance with the Safety Standard for Refrigeration Systems, ANSI/ASHRAE 15.
- Notice: Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- Notice: Component parts shall be replaced with like components so as to minimize the risk of possible ignition due to incorrect parts.
- The appliance is to be installed in accordance with the Safety
- WARNING: Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.
- Warning: The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation;
- Warning: The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater).

- **Warning:** The appliance shall be stored so as to prevent mechanical damage from occurring
- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges, or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.
- Before carrying out Decommissioning procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.
- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, **FLAMMABLE REFRIGERANTS**
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders

Details of Product

It uses quality, effective and hermetic compressor with broad range of starting voltage, suitable ambient temperature: not higher than 38°C/100°F, reasonable matching of the freezer system guarantees its powerful refrigerant ability and energy saving.

A good choice for storage of your variety of frozen food product. It is easy to lift up the lid to get your frozen food and close the lid to seal the freezer in.

Caution for Using

Unpack all packages before using the freezer. Don't bend it over more than 60° while moving it.

The freezer should be installed in the environment of good ventilation, Cool and dry and without corrosive gas. It should not be installed close to heat sources or directly under the sunlight. The space more than 10cm

between the wall of the front and the back of the freezer should be allowed. When installing, the wheels should be padded well so as to make the freezer be level and stable, or it will cause vibration and too much noise. If power is cut off, wait at least 5 minutes before turning on again to avoid damage to the compressor.

To save energy, the door should not be frequently opened for a long time. The surface and the inside of the freezer should be dry and clean. Long term moisture will cause the freezer rust slowly. (There will be some stains On the surface.)

Periodical cleaning is suggested for your reference. Generally, 30-45 days once is best. When cleaning, it is best to wipe the inside and the surface of the showcase with the soft cloth with neutral soap or detergent. Refrigerant class A3 per ANSI/ASHRAE 34

The maximum loading of each type of basket is 8kg.

Attention: To ensure safety, the power plug must be pulled out before cleaning. All safety precautions must be followed. Dispose of properly in accordance with Federal or local regulations. Risk of fire or explosion due to puncture of refrigerant tubing. Follow handling instructions carefully.


DANGER: Risk of fire or explosion. Flammable refrigerant R290/R600a used. To be repaired only by trained service personnel. Do not use mechanical devices to defrost refrigerator. Do not puncture refrigerant tubing.

ATTENTION: pour assurer la sécurité , la fiche d'alimentation doit être retirée avant le nettoyage. Toutes les précautions de sécurité doivent être respectées. Disposer correctement conformément aux réglementations fédérales ou locales. Risque d'incendie ou d'explosion dû à la perforation du tube réfrigérant. Suivre la manutention instructions soigneusement.

Danger: risque d'incendie ou d'explosion. Réfrigérant inflammable R290/R600a utilisé . Être réparé uniquement par un technicien qualifié .

N'utilisez pas de dispositifs mécaniques pour dégivrer le réfrigérateur. Ne pas perforer le tube réfrigérant.

Parts and features



Technical parameter


Model	Rated voltage (V)	Rated frequency (Hz)	Rated Current: (W)
BD-95JEW	115~	60	1.2A
BD-95JEB			
BD-142JEW			
BD-142JEB			
BD-192JEW			1.4A
BD-192JEB			

How to Use

Allow to stand for a minimum of 4 hours before plugging in to the mains. The temperature is controlled by the temperature control knob located on the front face, at the bottom right hand side. Rotate the control knob left or right to regulate the temperature inside the freezer.

When initial operation, the freezer should run empty about one hour before storing food in it.

Before placing food into the freezer, adjust the temperature control to the lowest point (highest number) and let it run until the temperature of inner cabinet decreases to 0°Fahrenheit (-18°Celsius). Put the food in, and after 12 hours adjust the temperature control to the normal point.



- Initially set the temperature to 6.8°F(-14°C)
- Place food inside the chest freezer after using it for 24 hours.
- Set the chest freezer to your desired setting using ▲ and ▼ buttons
- Press both ▲ and ▼ buttons at the same time for 3 seconds to lock and unlock control panel.
- The chest freezer has two temperature ranges: -14°F(-26°C) to 6.8°F(-14°C) and 32°F (0°C) to 50°F(10°C). If you increase the temperature past 6.8°F(-14°C), it will automatically jump to 32°F (0°C).
- When the compressor works continuously for 24 hours, it will stop automatically for 20 minutes before restarting again.
- In case you unplug your chest freezer or experience an electrical outage the unit will start 5 minutes after it is plugged back in or power is recovered. This is to protect the compressor.

To activate Fast Freeze Mode: Press  and hold for 3 seconds. The compressor will run for 24 hours and will stop after that period of time or when the inside temperature drops to -18°F(-28°C). What is Fast Freeze Mode? Fast Freeze Mode reduces the time it takes to freeze large amounts of fresh, unfrozen food. The faster food is frozen, the better the quality will be when the food is thawed. When do you need to activate Fast Freeze Mode? Depending on how much food you plan on freezing at once, you may need to activate Fast Freeze Mode. If you plan on freezing food between 4-11lbs., we recommend you activate freeze mode as you load it in. For anything over 11lbs. We recommend you activate Fast Freeze Mode at least three hours before placing the food in the freezer. For smaller amounts of food (2 lbs. or under) it's not necessary to use Fast Freeze Mode, since any other temperature setting will be able to freeze your food fast enough while still maintaining its quality.

Indicator lights

“**Power**” indicates the freezer is switched on.

“**Run**” indicates the compressor is working.

Food Storage

- Do not fill the freezer full of products. You should leave space between items and the inner surface of the cabinet, so as to keep good ventilation of cold air and freeze evenly. Do not put in any bottled or canned beverage with freezing point above the temperature in the cabinet when it is below zero.
- For foods that should be moisture-free or lose water easily, wrap them up with hermetical food bags or fresh films before putting in the cabinet for the sake of avoiding smell-mixing and reducing frosting.
- Storage of volatile and combustible gases, liquids such as strong alkalies, strong acids, petrol ,etc. is forbidden.
- Never put hot food directly in the freezer. Food should be cold or frozen before placing it inside.
- The cabinet is intended exclusively for the storage and/or display of packaged foods only.

Maintenance

- The freezer should be cleaned regularly. When cleaning, turn off the power, take out the foods in the cabinet, clean the inside using water or a little neutral detergent.
- Do not use boiling water, acid, chemical diluent, petrol and oil, or dirt-removing powder.
- Dry it after cleaning.
- Use light soap water when cleaning the door seal, apply a little of talcum powder on it after natural drying to extend its service life.
- Use soft cloth with water or a little detergent to clean the out surface. Note, keeping the power supply and lower part of connect wires away from water to avoid electricity leakage.
- Except common breakdowns, those who are not service technician should not take apart and repair the freezer on their own so as to avoid worsening the trouble. Unauthorized repair of electrical part such as compressor, temperature controller is forbidden.
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available on hand. A dry chemical or CO2 fire extinguisher should be adjacent to the charging area.

- Notice: Any person who is involved with working on or breaking into a
- refrigerant circuit should hold a current valid certificate from an
- industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
- Notice: Servicing shall only be performed as recommended by the equipment
- manufacturer. Maintenance and repair requiring the assistance of other skilled
- personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment shall be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- Checking for presence of refrigerant, the area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e., non-sparking, adequately sealed, or intrinsically safe.
- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times, the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.
- Detection of flammable refrigerants: Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

Defrosting

Defrost for better freezing efficiency when the frost film in the cabinet is 5mm/ 1/5" thick.


When defrosting, turn off the power, take out the frozen foods, open the door for warming and melting. Use soft cloth to absorb water and clean it up.

Extract the water conduit and put in a water container

Do not use sharp metal tools such as steel brush to clean the frost film when defrosting so as to avoid evaporator damage.

Never use hairdryers, electrical heaters or other such electrical appliances for defrosting.

When defrosting has finished drain the water in the bottom of the freezer by removing the cap, as illustrated below.



There is a water conduit at the bottom of the freezer, when defrosting, extract the rubber cover, the defrosted water will drip into the hole and flow out.

NOTES: PLEASE KEEP THE RUBBER COVER SAFE DURING THE DEFROSTING AND PUT IT BACK AFTER THE DEFROSTING IS COMPLETE

Trouble Shooting

Breakdown	Case	Removal method
The indicator is not on. The compressor does not start.	The plug isn't connected to the socket really.	Replug it.
	no power	Connect the socket with power.

The indicator is on ,but the compressor doesn't work and buzzes only	The power voltage is <98V in North America or <187V in Europe.	Put a power-regulator more than 1000W power together.
The compressor stops a minute after start, and restart after a few minutes, and so repeatedly.	The power voltage is >132V in North America or <242V in Europe	
The compressor works normally, but the temperature in the cabinet lowers too slowly.	The door is opened too frequently.	Reduce open times.
	The food in the cabinet is too much, and placed improperly.	Place foods properly keep place between them for ventilation of cold air.
	The frost film is too thick.	Take out foods and defrost.
	The surface of the condenser is too dirty.	Stop and clean the condenser.
	The door seals badly.	Adjust the door seal.
The noise is too loud	The freezer is placed unstably.	Place it stably.
	The fixing of the freezer is loose.	Tighten the fixing.
	there s contact between pipes.	Separate them.

The following are not faults:

When the freezer is working or after stopping for a while, the refrigerant in the pipes is cycling and gives out " running water " sounds.

The surface temperature of the compressor may be up 70~80°C/ 158 ~ 176°F when it is working.

The back side of step freezer gives out heat.

In rainy season, the outer surface of the cabinet may have dew, which makes no defects on normal use. Just dry it with a piece of cloth.

Manufacturer: Zhejinag XingXing Refrigeration Co.,Ltd.

Address: No.1688 Baiyunshan South Rd,Hongjia,Jiaojiang,Taizhou City,Zhejiang Province,China

E-mail: support@vevor.com






Upgrade · The Home Creator Way

CONGÉLATEUR COFFRE

Modèle : BD95J E W BD95J E B BD142J E W

BD142J E B BD192J E W BD192J E B

**MODÈLE: BD95JEW/BD95JEB/BD142JEW/BD142JEB/BD192 JUIF
BD192JEB**



< Image à titre indicatif seulement >

Voici le mode d'emploi original. Veuillez lire attentivement toutes les instructions du manuel avant utilisation. VEVOR se réserve le droit d'interpréter ce manuel à sa guise. L'apparence du produit que vous recevrez peut différer. Nous vous prions de nous excuser si nous ne vous informons pas des mises à jour techniques ou logicielles concernant notre produit.

	Avertissement – Afin de réduire les risques de blessure, utilisateur doit lire Veuillez lire attentivement le manuel d'instructions.
	ÉLIMINATION CORRECTE Ce le produit est soumis à la disposition de européen Directif 2012/19/CE. Le symbole représentant une roue arrière poubelle traversée Le symbole « through » indique que le produit nécessite séparé refuser collection dans le européen Syndicat. Ceci s'applique au produit et tous les accessoires marqué de ce symbole. Produits marqués de ce fait, ils ne peuvent pas être jetés avec les ordures ménagères ordinaires, mais doivent être déposés dans une collection point de recyclage électrique et appareils électroniques

Chers consommateurs,

Merci beaucoup d'avoir acheté nos produits. Afin de garantir votre sécurité et d'optimiser l'utilisation de ce congélateur, veuillez lire attentivement ce mode d'emploi.

- Les produits sont des congélateurs coffres commerciaux. Ces produits sont destinés exclusivement au stockage et/ou à la présentation de produits emballés qui ne sont pas des aliments potentiellement dangereux. Cet appareil n'est pas destiné à être utilisé par des personnes (y compris les enfants) dont les capacités physiques, sensorielles ou mentales sont réduites, ou qui manquent d'expérience et de connaissances, à moins qu'elles ne soient sous surveillance ou n'aient reçu d'instructions concernant l'utilisation de l'appareil par une personne responsable de sa sécurité.
- Les enfants doivent être surveillés afin de s'assurer qu'ils ne jouent pas avec l'appareil.
- Le nettoyage et l'entretien par l'utilisateur ne doivent pas être effectués par des enfants sans surveillance.

- Ne stockez pas de substances explosives telles que des aérosols contenant un propulseur inflammable dans cet appareil.
- Si le cordon d'alimentation est endommagé, il doit être remplacé par le fabricant, son agent de service ou une personne qualifiée de manière similaire afin d'éviter tout danger.

Veillez vous conformer à la réglementation locale concernant la mise au rebut de cet appareil contenant du gaz inflammable. Avant de le mettre au rebut, veuillez retirer les portes afin d'éviter tout risque d'ingestion par des enfants.

• **AVERTISSEMENT** – Veillez à ce que les ouvertures de ventilation, dans le boîtier de l'appareil ou dans la structure encastrée, ne soient pas obstruées.

• **AVERTISSEMENT** – N'utilisez pas de dispositifs mécaniques ni d'autres moyens pour accélérer le processus de dégivrage, autrement que selon les recommandations du fabricant

• **AVERTISSEMENT** – Ne pas endommager le circuit de réfrigérant.

• **AVERTISSEMENT** – N'utilisez pas d'appareils électriques à l'intérieur des zones de stockage des aliments compartiments de l'appareil, sauf s'ils sont du type recommandé par le fabricant.

Cet appareil est destiné à un usage domestique et similaire.

des applications telles que les espaces cuisine pour le personnel dans les magasins, les bureaux et autres environnements de travail ; fermes et clients dans des hôtels, motels et autres lieux d'hébergement ; restauration et activités similaires non commerciales applications.

• L'appareil ne doit pas être installé dans les couloirs ou les halls publics.

Veillez vous conformer à la réglementation locale concernant la mise au rebut de cet appareil contenant du gaz inflammable. Avant de le mettre au rebut, veuillez retirer les portes afin d'éviter tout risque d'accident pour les enfants.

• **Avertissement** : l'appareil doit être installé conformément aux normes nationales en matière d'installation électrique.

• L'appareil doit être installé conformément à la norme de sécurité pour les systèmes de réfrigération, ANSI/ASHRAE 15.

• **Avis** : L'entretien doit être effectué uniquement selon les recommandations du

Fabricant de l'équipement. Les opérations de maintenance et de réparation nécessitant l'intervention d'un personnel qualifié doivent être

effectuées sous la supervision d'une personne compétente en matière d'utilisation de fluides frigorigènes inflammables.

- Remarque : Les pièces détachées doivent être remplacées par des pièces identiques afin de minimiser le risque d'inflammation due à des pièces incorrectes.
- L'appareil doit être installé conformément aux normes de sécurité.
- **AVERTISSEMENT** : N'utilisez aucun moyen pour accélérer le processus de dégivrage ou pour

Nettoyer, sauf avec les produits recommandés par le fabricant. L'appareil doit être entreposé dans une pièce sans source d'ignition permanente. sources (par exemple : flammes nues, un appareil à gaz en fonctionnement ou un radiateur électrique en marche).

- Ne pas percer ni brûler.
- Sachez que les fluides frigorigènes peuvent être inodores.
- Avertissement : L'appareil doit être entreposé dans un endroit bien ventilé où la taille de la pièce correspond à la surface de la pièce spécifiée pour son fonctionnement ;
- Avertissement : L'appareil doit être entreposé dans une pièce sans flammes nues fonctionnant en continu (par exemple, un appareil à gaz en fonctionnement) et sources d'inflammation (par exemple un radiateur électrique en fonctionnement).
- Avertissement : L'appareil doit être rangé de manière à éviter tout dommage mécanique de se produire
- Vérifiez que le câblage ne sera pas soumis à l'usure, à la corrosion, à une pression excessive, à des vibrations, à des arêtes vives ou à tout autre facteur environnemental défavorable. Cette vérification doit également tenir compte des effets du vieillissement ou des vibrations continues provenant de sources telles que les compresseurs ou les ventilateurs.
- Avant de procéder à la mise hors service, il est essentiel que Le technicien connaît parfaitement l'équipement et tous ses détails. Il est recommandé, conformément aux bonnes pratiques, de récupérer tous les fluides frigorigènes en toute sécurité. Avant toute opération, un échantillon d'huile et de fluide frigorigène doit être prélevé afin de pouvoir être analysé avant la réutilisation du fluide récupéré. Il est essentiel que l'alimentation électrique soit disponible avant le début des travaux.
- Lors du retrait du réfrigérant d'un système, que ce soit pour l'entretien ou

Lors de la mise hors service, il est recommandé, par mesure de précaution, de retirer tous les fluides frigorigènes en toute sécurité.

- Le matériel de récupération doit être en bon état de fonctionnement et comporter un ensemble de

Les instructions concernant l'équipement disponible doivent être adaptées à la récupération de tous les fluides frigorigènes appropriés, y compris, le cas échéant, les fluides frigorigènes inflammables.

- Le fluide frigorigène récupéré doit être restitué au fournisseur dans le cylindre de récupération approprié, accompagné du bon de transfert des déchets correspondant.

Ne pas mélanger les fluides frigorigènes dans les unités de récupération et surtout pas dans les bouteilles.

Détails du produit

Il utilise un compresseur de qualité, efficace et hermétique avec une large gamme de

tension de démarrage, température ambiante appropriée : ne dépassant pas 38°C/100°F,

Un système de congélation correctement adapté garantit sa puissante capacité de réfrigération et ses économies d'énergie.

Un excellent choix pour conserver vos produits surgelés. Le couvercle est facile à soulever pour accéder aux aliments et à refermer pour une fermeture hermétique.

Précautions d'emploi

Déballez tous les emballages avant d'utiliser le congélateur. Ne le pliez pas à plus de 60° lors de sa manipulation.

Le congélateur doit être installé dans un environnement bien ventilé.

Dans un endroit frais et sec, exempt de gaz corrosifs, il ne doit pas être installé à proximité de sources de chaleur ni directement exposé au soleil.

Un espace de plus de 10 cm est recommandé.

Il convient de prévoir un espace entre la paroi avant et la paroi arrière du congélateur.

Lors de l'installation, les roues doivent être bien rembourrées afin de faciliter le roulement.

Le congélateur doit être de niveau et stable, sinon il provoquera des vibrations et trop de bruit.

En cas de coupure de courant, attendez au moins 5 minutes avant de rétablir le courant afin d'éviter d'endommager le compresseur.

Pour économiser de l'énergie, il ne faut pas laisser la porte ouverte fréquemment et longtemps.

La surface et l'intérieur du congélateur doivent être secs et propres. L'humidité ambiante provoquera lentement la rouille du congélateur. (Il y aura quelques taches.)

En surface.)

Un nettoyage périodique est conseillé. Généralement, tous les 30 à 45 jours.

Il est préférable de le faire une fois par jour. Lors du nettoyage, il est préférable d'essuyer l'intérieur et l'extérieur.

Nettoyer la surface de la vitrine avec un chiffon doux imbibé de savon neutre ou de détergent.

Réfrigérant de classe A3 selon la norme ANSI/ASHRAE 34

La charge maximale de chaque type de panier est de 8 kg.

Attention : Pour des raisons de sécurité, la prise d'alimentation doit être débranchée avant

cleaning. All safety precautions must be followed. Dispose of properly in accordance with Federal or local regulations. Risk of fire or explosion due to puncture of refrigerant tubing. Follow handling instructions carefully.


DANGER: Risk of fire or explosion. Flammable refrigerant R290/R600a used. To be repaired only by trained service personnel. Do not use mechanical devices to defrost refrigerator. Do not puncture refrigerant tubing.

ATTENTION: pour assurer la sécurité, la fiche d'alimentation doit être retirée avant le nettoyage. Toutes les précautions de sécurité doivent être respectées. Disposer correctement conformément aux réglementations fédérales ou locales. Risque d'incendie ou d'explosion dû à la perforation du tube réfrigérant. Suivre la manutention instructions soigneusement.

Danger: risque d'incendie ou d'explosion. Réfrigérant inflammable R290/R600a utilisé. Être réparé uniquement par un technicien qualifié.

N'utilisez pas de dispositifs mécaniques pour dégivrer le réfrigérateur. Ne pas perforer le tube réfrigérant.

Parts and features



- 8. Door
- 9. Handle Caster
- 10. Light
- 11. basket
- 12. Box feet
- 13. drain plug
- 14. Body

Technical parameter

Model	Rated voltage (V)	Rated frequency (Hz)	Rated Current: (W)
BD-95JEW	115 ~	60	1,2 A
BD-95JEB			
BD-142JEW			
BD-142JEB			
BD-192JEW			1,4 A
BD-192JEB			


Comment utiliser

Laisser reposer pendant au moins 4 heures avant de brancher l'appareil sur le secteur.

La température se règle à l'aide du bouton situé en bas à droite de la façade. Tournez le bouton vers la gauche ou vers la droite pour régler la température à l'intérieur du congélateur.

Lors de la première utilisation, il est conseillé de laisser le congélateur fonctionner à vide pendant environ une heure avant d'y entreposer des aliments.

Avant de placer les aliments au congélateur, réglez le thermostat au minimum (position la plus élevée) et laissez-le fonctionner jusqu'à ce que la température intérieure atteigne -18 °C (0 °F). Placez ensuite les aliments au congélateur et, après 12 heures, réglez le thermostat sur sa position habituelle.



- Réglez initialement la température à 6,8°F (-14°C).
- Placez les aliments dans le congélateur coffre après les avoir utilisés pendant 24 heures.
- Réglez le congélateur coffre sur le réglage souhaité à l'aide de ▲ et ▼ boutons
- Appuyez sur les deux ▲ et ▼ appuyez simultanément sur les boutons pendant 3 secondes pour verrouiller et Déverrouiller le panneau de contrôle.
- Le congélateur coffre possède deux plages de température : de -26 °C à -14 °C et de 0 °C à 10 °C. Si vous augmentez la température au-delà de cette plage, vous risquez de rencontrer des problèmes. 6,8°F (-14°C), il passera automatiquement à 32°F (0°C).
- Lorsque le compresseur fonctionne en continu pendant 24 heures, il s'arrête. automatiquement pendant 20 minutes avant de redémarrer.
- En cas de débranchement de votre congélateur coffre ou de panne de courant L'appareil démarrera 5 minutes après avoir été rebranché ou après une coupure de courant. récupéré. Ceci afin de protéger le compresseur.

Pour activer le mode congélation rapide : appuyez sur ❄️ et maintenez la pression pendant 3 secondes. Le compresseur fonctionnera pendant 24 heures et s'arrêtera après cette période. lorsque la température intérieure descend à -18 °F (-28 °C). Qu'est-ce que le mode Congélation rapide ? Le mode Congélation rapide réduit le temps nécessaire pour Congelez de grandes quantités d'aliments frais non congelés. Plus les aliments sont congelés rapidement, La qualité sera meilleure une fois les aliments décongelés. Quand faut-il activer le mode de congélation rapide ? Cela dépend de la quantité. Pour congeler en une seule fois les aliments que vous prévoyez de congeler, vous devrez peut-être activer la congélation rapide. Mode. Si vous prévoyez de congeler des aliments pesant entre 2 et 5 kg, nous vous recommandons de suivre ces instructions. Activez le mode gel pendant le chargement. Pour tout ce qui dépasse 450 g. Il est recommandé d'activer le mode de congélation rapide au moins trois

heures à l'avance. placer les aliments au congélateur. Pour les petites quantités (1 kg ou moins), il n'est pas nécessaire d'utiliser le mode de congélation rapide, car toute autre température Ce réglage permettra de congeler vos aliments assez rapidement tout en préservant leur fraîcheur. qualité.

Voyants indicateurs

« **Pouvoir** » indique le congélateur est commuté sur .

« **Exécuter** » indique le compresseur est fonctionnement .

Conservation des aliments

- Ne remplissez pas le congélateur à ras bord. Laissez de l'espace entre les produits.

Veillez à bien ventiler les objets et la surface intérieure du placard afin d'assurer une congélation uniforme. Ne placez aucune boisson en bouteille ou en canette.

avec un point de congélation supérieur à la température à l'intérieur de l'armoire lorsqu'elle est inférieure à zéro.

- Pour les aliments qui doivent être exempts d'humidité ou qui perdent facilement de l'eau, enveloppez-les dans des sacs alimentaires hermétiques ou des films plastiques neufs avant de les ranger dans le placard afin d'éviter le mélange des odeurs et de réduire le givrage.

- Le stockage de gaz volatils et combustibles, de liquides tels que les bases fortes, les acides forts, l'essence, etc., est interdit.

- Ne jamais mettre d'aliments chauds directement au congélateur. Les aliments doivent être froids ou congelés avant d'y être placés.

- Ce meuble est exclusivement destiné au stockage et/ou à la présentation d'aliments emballés.

Entretien

- Le congélateur doit être nettoyé régulièrement. Lors du nettoyage, éteignez-le.

Utilisez un appareil électrique, retirez les aliments du placard, nettoyez l'intérieur avec de l'eau ou un peu de détergent neutre.

- N'utilisez pas d'eau bouillante, d'acide, de diluant chimique, d'essence et d'huile, ni de poudre détachante.

- Séchez-le après le nettoyage.

- Pour nettoyer le joint de porte, utilisez de l'eau légèrement savonneuse et appliquez un peu de talc après séchage naturel afin d'en prolonger la durée de vie.

- Nettoyez la surface extérieure avec un chiffon doux imbibé d'eau ou d'un peu de détergent. Veillez à maintenir l'alimentation et la partie inférieure des câbles de connexion à l'écart de l'eau afin d'éviter tout risque de fuite électrique.

- Hormis les pannes courantes, ceux qui ne sont pas techniciens de maintenance

Il est déconseillé de démonter et de réparer soi-même le congélateur afin d'éviter d'aggraver le problème. Toute réparation non autorisée de pièces électriques, telles que...

Le compresseur et le régulateur de température sont interdits.

- Tout le personnel d'entretien et les autres personnes travaillant dans la zone locale doivent être Des instructions précises sur la nature des travaux à effectuer sont requises. Le travail en espaces confinés est à éviter.

- Si des travaux à chaud doivent être effectués sur l'équipement frigorifique ou toute pièce associée, un équipement d'extinction d'incendie approprié doit être installé.

Un extincteur à poudre chimique ou à CO2 doit être disponible à proximité de la zone de recharge.

- Avis : Toute personne impliquée dans des travaux ou une effraction dans un

- Le circuit frigorifique doit être muni d'un certificat valide délivré par un organisme agréé.

- un organisme d'évaluation accrédité par l'industrie, qui autorise leur compétence pour manipuler les fluides frigorigènes en toute sécurité conformément à un cahier des charges d'évaluation reconnu par l'industrie.

- Remarque : L'entretien doit être effectué uniquement selon les recommandations du fabricant de l'équipement.

- Fabricant. Maintenance et réparation nécessitant l'intervention d'autres techniciens qualifiés.

- Les travaux doivent être effectués par le personnel sous la supervision d'une personne compétente en matière d'utilisation de fluides frigorigènes inflammables.

Toute personne effectuant des travaux sur un SYSTÈME FRIGORIFIQUE impliquant la mise à nu de la tuyauterie ne doit utiliser aucune source d'inflammation susceptible de provoquer un incendie ou une explosion.

Toutes les sources d'inflammation possibles, y compris la cigarette, doivent être tenues à une distance suffisante du lieu d'installation, de réparation, de dépose ou de mise au rebut, opérations durant lesquelles du réfrigérant peut être libéré dans l'espace environnant. Avant toute

intervention, la zone autour de l'équipement doit être inspectée afin de s'assurer de l'absence de risques d'inflammation.

Des panneaux « Interdiction de fumer » doivent être affichés.

- Vérification de la présence de réfrigérant : la zone doit être contrôlée à l'aide d'un détecteur de réfrigérant approprié avant et pendant les travaux, afin de garantir que

Le technicien est conscient des atmosphères potentiellement toxiques ou inflammables. Assurez-vous que l'équipement de détection de fuites utilisé est adapté à toutes les situations.

fluides frigorigènes applicables, c'est-à-dire non étincelants, correctement scellés ou intrinsèquement sûrs.

- Assurez-vous que la zone est à l'air libre ou qu'elle est correctement ventilée.

avant d'intervenir sur le système ou d'effectuer des travaux à chaud. Un certain degré de

La ventilation doit être maintenue pendant toute la durée des travaux. Elle doit permettre de disperser en toute sécurité tout fluide frigorigène libéré et, de préférence, de l'évacuer vers l'extérieur, dans l'atmosphère.

- Lors du remplacement de composants électriques, ces derniers doivent être adaptés à l'usage prévu et conformes aux spécifications. Il convient de respecter scrupuleusement les consignes de maintenance et d'entretien du fabricant. En cas de doute, veuillez contacter le service technique du fabricant.

- Détection des fluides frigorigènes inflammables : En aucun cas il ne faut les sources potentielles d'inflammation doivent être utilisées dans la recherche ou la détection de

Fuites de réfrigérant. L'utilisation d'une lampe à halogénures métalliques (ou de tout autre détecteur utilisant une flamme nue) est interdite.

Dégivrage

Dégivrer pour une meilleure efficacité de congélation lorsque le film de givre dans l'armoire a une épaisseur de 5 mm / 1/5".


Pour décongeler, éteignez l'appareil, retirez les aliments congelés, ouvrez la porte pour les réchauffer et les faire fondre. Utilisez un chiffon doux pour absorber l'eau et essuyer.

Retirez le conduit d'eau et placez-le dans un récipient d'eau.

N'utilisez pas d'outils métalliques pointus, tels qu'une brosse en acier, pour nettoyer le film de givre lors du dégivrage afin d'éviter d'endommager l'évaporateur.

N'utilisez jamais de sèche-cheveux, de radiateurs électriques ou autres appareils électriques de ce type pour le dégivrage.

Une fois le dégivrage terminé, videz l'eau située au fond du congélateur en retirant le bouchon, comme illustré ci-dessous.



Il y a un conduit d'eau au bas du congélateur, lors du dégivrage, Retirez le couvercle en caoutchouc, l'eau dégivrée s'écoulera dans le trou puis s'écoulera par l'extérieur.

REMARQUES : VEUILLEZ CONSERVER LE COUVERCLE EN CAOUTCHOUC PENDANT LE DÉGIVRAGE ET LE REMETTRE EN PLACE UNE FOIS LE DÉGIVRAGE TERMINÉ.
COMPLET

Dépannage

Panne	Cas	Méthode d'élimination
Le voyant n'est pas allumé. Le compresseur ne démarre pas.	La prise n'est pas effectivement branché à la prise.	Rebranchez-le.
	pas de courant	Branchez la prise à l'alimentation.
Le voyant est allumé, mais le compresseur ne fonctionne pas et émet seulement un bourdonnement.	La tension d'alimentation est inférieure à 98 V au Nord. Amérique ou <187V en Europe.	Mettez un régulateur de puissance plus de Puissance totale de 1000 W.

Le compresseur arrête un minute après le début, et redémarrer après quelques minutes, et ainsi de suite.	La tension d'alimentation est supérieure à 132 V au Nord. Amérique ou <242V en Europe	
Le compresseur fonctionne normalement. mais la température dans l'armoire descend trop lentement.	La porte est ouverte trop souvent.	Réduire les heures d'ouverture.
	La nourriture dans le Le meuble est trop beaucoup, et mal placées.	Placer les aliments maintenir correctement l'espace entre eux pour ventilation de air froid.
	La couche de givre est trop épaisse.	Sortez les aliments et décongelez-les.
	La surface du condenseur est trop sale.	Arrêtez et nettoyez le condenseur.
	La porte ferme mal.	Ajustez le joint de porte.
Le bruit est trop fort.	Le congélateur est placé de manière instable.	Placez-le de manière stable.
	La fixation du congélateur est desserrée.	Resserrer la fixation.
	Il y a contact entre les tuyaux.	Séparez-les.

Les éléments suivants ne sont pas des défauts :

Lorsque le congélateur fonctionne ou après un arrêt prolongé, le fluide frigorigène dans les tuyaux circule en boucle et produit un bruit de « l'eau qui coule ».

La température de surface du compresseur peut atteindre 70 à 80 °C / 158 à 176 °F lorsqu'il est en fonctionnement.

La face arrière du congélateur à marches dégage de la chaleur.

En saison des pluies, de la rosée peut se former sur la surface extérieure du meuble, sans que cela n'affecte son utilisation normale. Il suffit de l'essuyer avec un chiffon.

Fabricant : Zhejinag XingXing Refrigeration Co., Ltd.

Adresse : n° 1688 Baiyunshan South Rd, Hongjia, Jiaojiang, ville de Taizhou, province du Zhejiang, Chine

Courriel : support@vevor.com






Upgrade · The Home Creator Way

Gefriertruhe

Modell: BD95J E W BD95J E B BD142J E W

BD142J E B BD192J E W BD192J E B

**MODELL: BD95JEW/BD95JEB/BD142JEW/BD142JEB/BD192 JUDE
BD192JEB**



< Abbildung dient nur als Referenz >

Dies ist die Originalanleitung. Bitte lesen Sie die gesamte Bedienungsanleitung vor der Inbetriebnahme sorgfältig durch. VEVOR behält sich die Auslegung der Bedienungsanleitung vor. Das Aussehen des Produkts kann von dem gelieferten Produkt abweichen. Wir bitten um Verständnis, dass wir Sie nicht erneut über etwaige Technologie- oder Software-Updates informieren werden .

	Warnung – Um das Risiko zu verringern Verletzung, Benutzer muss lesen Bitte lesen Sie die Bedienungsanleitung sorgfältig durch.
	KORREKTE ENTSORGUNG Das Das Produkt unterliegt der Bestimmung von europäisch Richtlinie 2012/19/EG. Das Symbol zeigt einen Wheelie. Mülleimer durchgestrichen „durch“ bedeutet, dass das Produkt erfordert separate verweigern Sammlung im europäisch Union. Dies gilt für das Produkt und sämtliches Zubehör Mit diesem Symbol gekennzeichnet. Produkte mit der Kennzeichnung Daher darf er nicht mit dem normalen Hausmüll entsorgt werden, sondern muss zu einer Sammlung gebracht werden Recyclingstelle elektrisch Und elektronische Geräte

Sehr geehrte Verbraucherinnen und Verbraucher:

Vielen Dank für den Kauf unserer Produkte. Um Ihre Sicherheit zu gewährleisten und die optimale Leistung Ihres Gefrierschranks zu erzielen, lesen Sie diese Anleitung bitte sorgfältig durch.

- Bei den Produkten handelt es sich um gewerbliche Gefriertruhen. Diese Produkte sind

ausschließlich zur Lagerung und/oder Präsentation von verpackten Produkten bestimmt, bei denen es sich nicht um potenziell gefährliche Lebensmittel handelt.

- Dieses Gerät ist nicht für die Verwendung durch Personen (einschließlich Kinder) mit eingeschränkten physischen, sensorischen oder geistigen Fähigkeiten oder mangelnder Erfahrung und Kenntnis bestimmt, es sei denn, sie werden beaufsichtigt oder angeleitet. betreffend die Verwendung des Geräts durch eine für ihre Sicherheit verantwortliche Person.

- Kinder sollten beaufsichtigt werden, um sicherzustellen, dass sie nicht mit dem Gerät spielen.

- Reinigungs- und Wartungsarbeiten dürfen nicht von Kindern ohne Aufsicht durchgeführt werden.
 - In diesem Gerät dürfen keine explosiven Stoffe wie Aerosoldosen mit entzündlichem Treibmittel gelagert werden.
 - Wenn das Netzkabel beschädigt ist, muss es vom Hersteller, seinem Kundendienst oder einer ähnlich qualifizierten Person ersetzt werden, um eine Gefährdung zu vermeiden.
- Bitte beachten Sie die örtlichen Vorschriften zur Entsorgung des Geräts aufgrund der brennbaren Gase. Entfernen Sie vor der Entsorgung die Türen, um zu verhindern, dass Kinder eingeschlossen werden.
- **WARNUNG** – Halten Sie die Belüftungsöffnungen im Gerätegehäuse oder in der Einbaukonstruktion frei von Verstopfungen.
 - **WARNUNG** – Verwenden Sie keine mechanischen Geräte oder andere Mittel, um den Auftauvorgang beschleunigen, außer den vom Hersteller empfohlenen.
 - **WARNUNG** – Den Kältemittelkreislauf nicht beschädigen.
 - **WARNUNG** – Verwenden Sie keine elektrischen Geräte im Lebensmittellager.
- Fächer des Geräts, es sei denn, es handelt sich um den vom Hersteller empfohlenen Typ.
- Dieses Gerät ist für den Gebrauch in Haushalten und ähnlichen Einrichtungen bestimmt.
- Anwendungsbereiche wie beispielsweise Personalküchen in Geschäften, Büros und anderen Einrichtungen
Arbeitsumgebungen; Bauernhöfe und von Kunden in Hotels, Motels und anderen Wohnumgebungen; Gastronomie und ähnliche Dienstleistungen außerhalb des Einzelhandels
Anwendungen.
- Das Gerät darf nicht in öffentlichen Fluren oder Eingangshallen installiert werden.
- Bitte beachten Sie die örtlichen Vorschriften zur Entsorgung des Geräts aufgrund der enthaltenen brennbaren Gase. Entfernen Sie vor der Entsorgung bitte die Türen, um zu verhindern, dass Kinder eingeschlossen werden.
- **Warnung:** Das Gerät muss gemäß den nationalen Verdrahtungsvorschriften installiert werden.
 - Das Gerät ist gemäß der Sicherheitsnorm für Kältesysteme, ANSI/ASHRAE 15, zu installieren.
 - **Hinweis:** Wartungsarbeiten dürfen nur gemäß den Empfehlungen des Herstellers durchgeführt werden.

Gerätehersteller. Wartungs- und Reparaturarbeiten, die die Unterstützung anderer Fachkräfte erfordern, sind unter der Aufsicht einer für den Umgang mit brennbaren Kältemitteln sachkundigen Person durchzuführen.

- Hinweis: Bauteile müssen durch gleichartige Bauteile ersetzt werden, um das Risiko einer möglichen Entzündung durch falsche Teile zu minimieren.

- Das Gerät ist gemäß den Sicherheitsvorschriften zu installieren.

- **WARNUNG:** Verwenden Sie keine Mittel, um den Auftauvorgang zu beschleunigen oder um

Reinigen Sie das Gerät nur mit den vom Hersteller empfohlenen Reinigungsmitteln. Das Gerät muss in einem Raum ohne ständig laufende Zündung aufbewahrt werden.

Quellen (zum Beispiel: offene Flammen, ein eingeschaltetes Gasgerät oder eine eingeschaltete elektrische Heizung).

- Nicht durchstechen oder verbrennen.

- Beachten Sie, dass Kältemittel geruchlos sein können.

- **Warnung:** Das Gerät muss in einem gut belüfteten Raum aufbewahrt werden, dessen Größe der für den Betrieb angegebenen Raumgröße entspricht;

- **Warnung:** Das Gerät muss in einem Raum ohne ständig brennende offene Flammen (z. B. in Betrieb befindliche Gasgeräte) aufbewahrt werden.

Zündquellen (z. B. eine eingeschaltete elektrische Heizung).

- **Warnung:** Das Gerät muss so gelagert werden, dass mechanische Beschädigungen vermieden werden.

dass

- Prüfen Sie, ob die Verkabelung Verschleiß, Korrosion, übermäßigem Druck, Vibrationen, scharfen Kanten oder anderen schädlichen Umwelteinflüssen ausgesetzt ist. Berücksichtigen Sie dabei auch die Auswirkungen von Alterung oder kontinuierlichen Vibrationen, beispielsweise durch Kompressoren oder Ventilatoren.

- Vor Durchführung des Stilllegungsverfahrens ist es unerlässlich, dass Der Techniker kennt die Ausrüstung und alle ihre Details in- und auswendig.

Es wird empfohlen, alle Kältemittel sicher zurückzugewinnen. Vor Beginn der Arbeiten sind Öl- und Kältemittelproben zu entnehmen, falls vor der Wiederverwendung des zurückgewonnenen Kältemittels eine Analyse erforderlich ist.

Es ist unerlässlich, dass vor Beginn der Arbeiten Strom zur Verfügung steht.

- Beim Entfernen von Kältemittel aus einem System, sei es zur Wartung oder

Bei der Stilllegung ist es ratsam, alle Kältemittel sicher zu entfernen.

- Die Bergungsausrüstung muss in einwandfreiem Zustand sein und über einen Satz von

Anweisungen bezüglich der vorhandenen Ausrüstung, die für die Rückgewinnung aller geeigneten Kältemittel, einschließlich gegebenenfalls brennbarer Kältemittel, geeignet sein muss.

- Das zurückgewonnene Kältemittel ist im korrekten Rückgewinnungszylinder und dem entsprechenden Abfallbegleitschein an den Kältemittellieferanten zurückzusenden.

Vorschrift. Kältemittel in Rückgewinnungsanlagen und insbesondere nicht in Zylindern mischen.

Produktdetails

Es verwendet einen hochwertigen, effizienten und hermetischen Kompressor mit einem breiten Spektrum an

Anlaufspannung, geeignete Umgebungstemperatur: nicht höher als 38°C/100°F,

Eine sinnvolle Abstimmung des Gefriersystems gewährleistet dessen hohe Kühlleistung und Energieeinsparung.

Eine gute Wahl zur Aufbewahrung Ihrer verschiedenen Tiefkühlprodukte.

Der Deckel lässt sich leicht anheben, um die Tiefkühlkost zu entnehmen, und wieder schließen, um den Gefrierschrank luftdicht zu verschließen.

Vorsicht bei der Verwendung

Packen Sie alle Pakete aus, bevor Sie den Gefrierschrank benutzen.

Achten Sie beim Transport darauf, dass die Temperatur 60° nicht überschreitet.

Der Gefrierschrank sollte in einer gut belüfteten Umgebung aufgestellt werden.

Kühl, trocken und frei von korrosiven Gasen. Nicht in der Nähe von Wärmequellen oder in direkter Sonneneinstrahlung installieren. Der Abstand sollte 10 cm nicht überschreiten.

Zwischen der Vorder- und der Rückwand des Gefrierschranks sollte ein gewisser Abstand eingehalten werden.

Bei der Montage sollten die Räder gut gepolstert werden, um die Der Gefrierschrank muss waagrecht und stabil stehen, sonst verursacht er Vibrationen und zu viel Lärm.

Wenn die Stromversorgung unterbrochen wird, warten Sie mindestens 5 Minuten, bevor Sie sie wieder einschalten, um Schäden am Kompressor zu vermeiden.

Um Energie zu sparen, sollte die Tür nicht häufig und lange geöffnet bleiben.

Die Oberfläche und das Innere des Gefrierschranks sollten trocken und sauber sein.

Anhaltende Feuchtigkeit führt langsam zu Rost im Gefrierschrank. (Es werden Flecken entstehen.)

Oberflächlich betrachtet .)

Zur Orientierung wird eine regelmäßige Reinigung empfohlen. Im Allgemeinen 30–45 Minuten.

Einmal täglich ist am besten. Bei der Reinigung sollte man die Innenseite und die Außenseite abwischen.

Reinigen Sie die Oberfläche der Vitrine mit einem weichen Tuch und neutraler Seife oder einem Reinigungsmittel.

Kältemittelklasse A3 gemäß ANSI/ASHRAE 34

Die maximale Beladung jedes Korbtyps beträgt 8 kg.

Achtung: Aus Sicherheitsgründen muss der Netzstecker vor dem Öffnen herausgezogen werden.

Reinigung. Alle Sicherheitsvorkehrungen sind zu beachten. Entsorgung gemäß Bundes- oder Landesvorschriften. Brand- oder Explosionsgefahr durch Beschädigung der Kältemittelleitung. Handhabungshinweise sorgfältig befolgen.

GEFAHR: Brand- oder Explosionsgefahr. Brennbares Kältemittel R290/R600a wird verwendet. Reparaturen dürfen nur von geschultem Fachpersonal durchgeführt werden. Nicht verwenden Mechanische Geräte zum Abtauen des Kühlschranks verwenden. Kältemittelleitungen nicht beschädigen.


VORSICHT: Aus Sicherheitsgründen muss der Netzstecker ...

Vor der Reinigung entfernen. Alle Sicherheitsvorkehrungen beachten. Gemäß den geltenden Bundes- oder Landesvorschriften ordnungsgemäß entsorgen. Brand- oder Explosionsgefahr durch Beschädigung der Kältemittelleitung. Handhabungshinweise sorgfältig befolgen.

Gefahr: Brand- oder Explosionsgefahr. Nicht brennbares Kältemittel.

Verwendetes Kältemittel: R290/R600a. Reparaturen dürfen nur von einem qualifizierten Techniker durchgeführt werden. Verwenden Sie keine mechanischen Geräte zum Abtauen des Kühlschranks. Beschädigen Sie nicht die Kältemittelleitung.

Teile und Merkmale



Technischer Parameter

Modell	Bewertung Spannung (V)	Bewertung Frequenz (Hz)	Nennstrom : (W)
BD-95JEW	115 ~	60	1.2A
BD-95JEB			
BD-142JEW			
BD-142JEB			
BD-192JEW			1.4A
BD-192JEB			


Anleitung zur Verwendung

Vor dem Anschließen an das Stromnetz mindestens 4 Stunden ruhen lassen.

Die Temperatur wird über den Temperaturreglerknopf an der Vorderseite unten rechts eingestellt. Drehen Sie den Reglerknopf nach links oder rechts, um die Temperatur im Gefrierschrank zu regulieren.

Bei der ersten Inbetriebnahme sollte der Gefrierschrank etwa eine Stunde lang leer laufen, bevor Lebensmittel eingelagert werden.

Bevor Sie Lebensmittel in den Gefrierschrank legen, stellen Sie den Temperaturregler auf die niedrigste Stufe (höchste Zahl) und lassen Sie das Gerät laufen, bis die Innentemperatur auf 0 °F (-18 °C) gesunken ist. Legen Sie die Lebensmittel hinein und stellen Sie den Temperaturregler nach 12 Stunden wieder auf die normale Temperatur ein.



- Stellen Sie die Temperatur zunächst auf 6,8°F (-14°C) ein.
- Legen Sie Lebensmittel nach 24 Stunden Gebrauch wieder in die Gefriertruhe.
- Stellen Sie die Gefriertruhe auf die gewünschte Einstellung ein. ▲ und ▼ Knöpfe
- Drücken Sie beide Tasten ▲ Und ▼ Zum Sperren die Tasten gleichzeitig 3 Sekunden lang gedrückt halten. Und Bedienfeld entsperren.
- Die Gefriertruhe hat zwei Temperaturbereiche: -14 °F (-26 °C) bis 6,8 °F (-14 °C) und 32 °F (0 °C) bis 50 °F (10 °C). Wenn Sie die Temperatur über diesen Bereich hinaus erhöhen, ... Bei -14 °C (6,8 °F) springt die Temperatur automatisch auf 0 °C (32 °F).
- Wenn der Kompressor 24 Stunden lang ununterbrochen läuft, schaltet er sich ab. automatisch für 20 Minuten, bevor es von neuem startet.
- Falls Sie Ihre Gefriertruhe vom Stromnetz trennen oder einen Stromausfall erleiden Das Gerät startet 5 Minuten nach dem Wiedereinstecken oder dem Abschalten der Stromversorgung. wiederhergestellt. Dies dient dem Schutz des Kompressors.

Zum Aktivieren des Schnellgefriermodus: Drücken Sie ❄️ und 3 Sekunden lang gedrückt halten. Der Kompressor läuft 24 Stunden lang und schaltet sich nach dieser Zeit ab. Wenn die Innentemperatur auf -18 °F (-28 °C) sinkt. Was ist der Schnellgefriermodus? Der Schnellgefriermodus verkürzt die Zeit, die zum Einfrieren benötigt wird. Große Mengen frischer, nicht gefrorener Lebensmittel einfrieren. Je schneller die Lebensmittel eingefroren sind, desto besser. Die Qualität ist besser, wenn die Lebensmittel aufgetaut sind. Wann muss der Schnellgefriermodus aktiviert werden? Das hängt davon ab, wie viel Wenn Sie Lebensmittel auf einmal einfrieren möchten, müssen Sie möglicherweise die Schnellgefrierfunktion aktivieren. Modus. Wenn Sie planen, Lebensmittel mit einem Gewicht zwischen 4 und 11 Pfund einzufrieren, empfehlen wir Ihnen Aktivieren Sie den Gefriermodus beim Einladen. Für alles über 1 Pfund. Wir empfehlen Ihnen, den Schnellgefriermodus mindestens drei Stunden vorher zu aktivieren. Legen

Sie die Lebensmittel in den Gefrierschrank. Bei kleineren Mengen (bis zu 1 kg) ist die Schnellgefrierfunktion nicht notwendig, da jede andere Temperatur ausreicht. Mit dieser Einstellung können Sie Ihre Lebensmittel schnell genug einfrieren und gleichzeitig deren Konsistenz bewahren. Qualität.

Kontrollleuchten

„ **Leistung** “ bedeutet Die Gefrierschrank Ist umgeschaltet An .

„ **Run** “ bedeutet Die Kompressor Ist funktioniert .

Lebensmittellagerung

- Füllen Sie den Gefrierschrank nicht bis zum Rand mit Produkten. Lassen Sie Platz zwischen den Produkten.

Die Gegenstände und die Innenfläche des Schrankes sollten so angeordnet werden, dass eine gute Belüftung mit kalter Luft gewährleistet ist und die Lebensmittel gleichmäßig eingefroren werden. Stellen Sie keine Flaschen- oder Dosengetränke hinein.

mit einem Gefrierpunkt oberhalb der Temperatur im Schrank, wenn diese unter Null Grad liegt.

- Lebensmittel, die trocken bleiben sollten oder leicht Wasser verlieren, sollten vor dem Einräumen in den Schrank in luftdichte Gefrierbeutel oder Frischhaltefolie eingewickelt werden, um eine Vermischung der Gerüche zu vermeiden und die Bildung von Frost zu reduzieren.

- Die Lagerung von leicht entzündlichen Gasen und Flüssigkeiten wie starken Laugen, starken Säuren, Benzin usw. ist verboten.

- Heiße Speisen niemals direkt in den Gefrierschrank stellen. Die Speisen sollten kalt oder gefroren sein, bevor sie hineingelegt werden.

- Der Schrank ist ausschließlich zur Aufbewahrung und/oder Präsentation von verpackten Lebensmitteln bestimmt.

Wartung

- Der Gefrierschrank sollte regelmäßig gereinigt werden. Schalten Sie ihn beim Reinigen aus.

Schalten Sie den Strom aus, nehmen Sie die Lebensmittel aus dem Schrank und reinigen Sie das Innere mit Wasser oder etwas neutralem Reinigungsmittel.

- Verwenden Sie kein kochendes Wasser, keine Säure, keine chemischen Verdünnungsmittel, kein Benzin und kein Öl und kein Schmutzentfernungspulver.

- Nach der Reinigung trocknen lassen.

- Reinigen Sie die Türdichtung mit milder Seifenlauge und bestäuben Sie sie nach dem natürlichen Trocknen mit etwas Talkumpuder, um ihre Lebensdauer zu verlängern.
 - Reinigen Sie die Außenfläche mit einem weichen Tuch und Wasser oder etwas Spülmittel. Achten Sie darauf, dass das Netzteil und die unteren Anschlusskabel nicht mit Wasser in Berührung kommen, um Stromschläge zu vermeiden.
 - Abgesehen von üblichen Ausfällen, diejenigen, die keine Servicetechniker sind
- Sie sollten den Gefrierschrank nicht selbst auseinandernehmen und reparieren, um eine Verschlimmerung des Problems zu vermeiden. Nicht autorisierte Reparaturen an elektrischen Teilen wie z. B. Kompressor und Temperaturregler sind verboten.
- Sämtliches Wartungspersonal und alle anderen im lokalen Bereich tätigen Personen müssen Sie wurden über die Art der auszuführenden Arbeiten belehrt. Arbeiten in beengten Räumen sind zu vermeiden.
 - Falls an der Kälteanlage oder zugehörigen Teilen Schweißarbeiten durchgeführt werden sollen, müssen geeignete Feuerlöscheinrichtungen bereitgestellt werden.
- Ein Pulver- oder CO₂-Feuerlöscher sollte in der Nähe des Ladebereichs bereitliegen.
- Hinweis: Jede Person, die an Arbeiten an oder dem Einbruch in ein Gebäude beteiligt ist,
 - Der Kältemittelkreislauf sollte über ein gültiges Zertifikat einer Prüfstelle verfügen.
 - eine branchenweit anerkannte Bewertungsstelle, die ihre Kompetenz zum sicheren Umgang mit Kältemitteln gemäß einer branchenweit anerkannten Bewertungsspezifikation.
 - Hinweis: Wartungsarbeiten dürfen nur gemäß den Empfehlungen des Geräteherstellers durchgeführt werden.
 - Hersteller. Wartung und Reparatur erfordern die Unterstützung anderer Fachkräfte.
 - Die Arbeiten des Personals müssen unter der Aufsicht einer für den Umgang mit brennbaren Kältemitteln sachkundigen Person durchgeführt werden.
 - Personen, die Arbeiten an Kälteanlagen durchführen, bei denen Rohrleitungen freigelegt werden, dürfen keine Zündquellen so verwenden, dass Brand- oder Explosionsgefahr besteht. Alle möglichen Zündquellen, einschließlich Zigarettenrauch, müssen in ausreichendem Abstand vom Ort der Installation, Reparatur, Demontage und Entsorgung gehalten werden, da dabei Kältemittel in die Umgebung austreten kann. Vor Beginn

der Arbeiten ist der Bereich um die Anlage auf brennbare Stoffe und Zündgefahren zu überprüfen.

Es müssen Schilder mit der Aufschrift „Rauchen“ angebracht werden.

- Um sicherzustellen, dass kein Kältemittel vorhanden ist, muss der Bereich vor und während der Arbeiten mit einem geeigneten Kältemitteldetektor überprüft werden.

Der Techniker ist sich der potenziell toxischen oder entzündlichen Atmosphären bewusst. Stellen Sie sicher, dass das verwendete Lecksuchgerät für den Einsatz mit allen Atmosphären geeignet ist. Geeignete Kältemittel, d.h. funkenfrei, ausreichend abgedichtet oder eigensicher.

- Stellen Sie sicher, dass sich der Bereich im Freien befindet oder ausreichend belüftet ist.

bevor man in das System einbricht oder irgendwelche Arbeiten durchführt. Ein gewisses Maß an

Die Belüftung muss während der gesamten Bauzeit aufrechterhalten werden. Dabei ist darauf zu achten, dass freigesetztes Kältemittel sicher abgeführt und vorzugsweise nach außen in die Atmosphäre abgeleitet wird.

- Werden elektrische Bauteile ausgetauscht, müssen diese für den vorgesehenen Zweck geeignet sein und den korrekten Spezifikationen entsprechen. Die Wartungs- und Servicehinweise des Herstellers sind stets zu beachten. Im Zweifelsfall wenden Sie sich bitte an die technische Abteilung des Herstellers.

- Nachweis brennbarer Kältemittel: Unter keinen Umständen darf potenzielle Zündquellen können bei der Suche oder Erkennung von Kältemittellecks. Ein Halogenbrenner (oder ein anderes Detektorgerät mit offener Flamme) darf nicht verwendet werden.

Auftauen

Für eine bessere Gefrierleistung abtauen, wenn die Frostschrift im Gefrierschrank 5 mm / 1/5 Zoll dick ist.


Zum Auftauen den Strom abschalten, die gefrorenen Lebensmittel entnehmen und die Tür zum Erwärmen und Auftauen öffnen.

Anschließend das Wasser mit einem weichen Tuch aufsaugen und die Lebensmittel reinigen.

Ziehen Sie die Wasserleitung heraus und legen Sie sie in einen Wasserbehälter.

Verwenden Sie beim Abtauen keine scharfen Metallwerkzeuge wie z. B. Stahlbürsten, um den Frostfilm zu entfernen und so eine Beschädigung des Verdampfers zu vermeiden.

Verwenden Sie zum Abtauen niemals Haartrockner, elektrische Heizgeräte oder ähnliche elektrische Geräte.
 Wenn der Abtauvorgang abgeschlossen ist, lassen Sie das Wasser im Boden des Gefrierschranks ab, indem Sie den Deckel abnehmen, wie



unten abgebildet.

Am Boden des Gefrierschranks befindet sich eine Wasserleitung, die beim Abtauen benötigt wird.

Entfernen Sie die Gummikappe; das aufgetaute Wasser tropft in das Loch und fließt heraus.

HINWEIS: Bitte bewahren Sie die Gummiabdeckung während des Abtauvorgangs sicher auf und legen Sie sie nach dem Abtauen wieder auf.
VOLLSTÄNDIG

Fehlerbehebung

Abbauen	Fall	Entfernungsmethod e
Die Kontrollleuchte ist nicht eingeschaltet. Der Kompressor startet nicht.	Der Stecker ist nicht tatsächlich mit der Steckdose verbunden.	Stecken Sie es wieder ein.
	Kein Strom	Schließen Sie die Steckdose an die Stromversorgung an.
Die Kontrollleuchte leuchtet, aber der Kompressor funktioniert nicht und brummt nur.	Die Netzspannung beträgt in Nordengland <98 V. Amerika oder <187V in Europa.	Setze ein Leistungsregler mehr als 1000W Leistung zusammen.

Der Kompressor stoppt Minute nach dem Start und Nach einigen Minuten neu starten und so weiter.	Die Netzspannung beträgt in Nordengland >132 V. Amerika oder <242V in Europa	
Der Kompressor funktioniert normal. aber die Temperatur im Schrank sinkt zu langsam.	Die Tür wird zu oft geöffnet.	Öffnungszeiten verkürzen.
	Das Essen im Der Schrank ist zu viel und unsachgemäß platziert.	Essen verzehren Halten Sie den Abstand zwischen ihnen richtig ein, Belüftung von kalte Luft.
	Die Frostschrift ist zu dick.	Lebensmittel herausnehmen und auftauen lassen.
	Die Oberfläche des Kondensators ist zu schmutzig.	Halten Sie an und reinigen Sie den Kondensator.
	Die Tür dichtet schlecht ab.	Türdichtung einstellen.
Der Lärm ist zu laut	Der Gefrierschrank steht instabil.	Stellen Sie es stabil auf.
	Die Befestigung des Gefrierschranks ist locker.	Die Befestigung festziehen.
	Es besteht Kontakt zwischen den Rohren.	Trennen Sie sie.

Folgende Punkte stellen keine Fehler dar:

Wenn der Gefrierschrank in Betrieb ist oder nach einer längeren Stillstandszeit, zirkuliert das Kältemittel in den Leitungen und erzeugt dabei Geräusche, die an fließendes Wasser erinnern.

Die Oberflächentemperatur des Kompressors kann im Betrieb bis zu 70~80°C/ 158 ~ 176°F betragen.

Die Rückseite des Gefrierschranks gibt Wärme ab.

In der Regenzeit kann sich auf der Außenseite des Schranks Tau bilden, was bei normalem Gebrauch jedoch keine Beeinträchtigung darstellt.

Trocknen Sie ihn einfach mit einem Tuch ab.

Hersteller: Zhejinag XingXing Refrigeration Co., Ltd.

Adresse: Nr. 1688 Baiyunshan South Rd, Hongjia, Jiaojiang, Stadt Taizhou, Provinz Zhejiang, China

E-Mail: support@vevor.com






Upgrade · The Home Creator Way

CHEST FREEZER

Model:BD95JEW BD95JEB BD142JEW

BD142JEB BD192JEW BD192JEB

**MODEL: BD95JEW/BD95JEB/BD142JEW/BD142JEB/BD192JEW
BD192JEB**



<Picture Only For Reference >

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

	Warning-To reduce the risk of injury, user must read instructions manual carefully.
	CORRECT DISPOSAL This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheeled bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices

Dear Consumers:

Thank you very much for purchasing our products. In order to ensure your safety and achieve the best out of this freezer, please read this instruction carefully.

- The products are commercial chest freezers. These products are intended solely for the storage and/or display of packaged products that are not potentially hazardous foods.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Please according to local regulations regarding disposal of the appliance for its flammable blowing gas. Before you scrap the appliance, please take off the doors to prevent children trapped.

- WARNING – Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- WARNING – Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer
- WARNING – Do not damage the refrigerant circuit.
- WARNING – Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance is intended to be used in household and similar applications such as, staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; Catering and similar non-retail applications.
- The appliance shall not be installed in public corridors or lobbies.
Please according to local regulations regarding disposal of the appliance for its flammable gas. Before you scrap the appliance, please take off the doors to prevent children trapped
- Warning: the appliance shall be installed in accordance with national wiring regulations
- The appliance is to be installed in accordance with the Safety Standard for Refrigeration Systems, ANSI/ASHRAE 15.
- Notice: Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- Notice: Component parts shall be replaced with like components so as to minimize the risk of possible ignition due to incorrect parts.
- The appliance is to be installed in accordance with the Safety
- WARNING: Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.
- Warning: The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation;
- Warning: The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater).

- **Warning:** The appliance shall be stored so as to prevent mechanical damage from occurring
- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges, or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.
- Before carrying out Decommissioning procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.
- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, **FLAMMABLE REFRIGERANTS**
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders

Details of Product

It uses quality, effective and hermetic compressor with broad range of starting voltage, suitable ambient temperature: not higher than 38°C/100°F, reasonable matching of the freezer system guarantees its powerful refrigerant ability and energy saving.

A good choice for storage of your variety of frozen food product. It is easy to lift up the lid to get your frozen food and close the lid to seal the freezer in.

Caution for Using

Unpack all packages before using the freezer. Don't bend it over more than 60° while moving it.

The freezer should be installed in the environment of good ventilation, Cool and dry and without corrosive gas. It should not be installed close to heat sources or directly under the sunlight. The space more than 10cm

between the wall of the front and the back of the freezer should be allowed. When installing, the wheels should be padded well so as to make the freezer be level and stable, or it will cause vibration and too much noise. If power is cut off, wait at least 5 minutes before turning on again to avoid damage to the compressor.

To save energy, the door should not be frequently opened for a long time. The surface and the inside of the freezer should be dry and clean. Long term moisture will cause the freezer rust slowly. (There will be some stains On the surface.)

Periodical cleaning is suggested for your reference. Generally, 30-45 days once is best. When cleaning, it is best to wipe the inside and the surface of the showcase with the soft cloth with neutral soap or detergent. Refrigerant class A3 per ANSI/ASHRAE 34

The maximum loading of each type of basket is 8kg.

Attention: To ensure safety, the power plug must be pulled out before cleaning. All safety precautions must be followed. Dispose of properly in accordance with Federal or local regulations. Risk of fire or explosion due to puncture of refrigerant tubing. Follow handling instructions carefully.


DANGER: Risk of fire or explosion. Flammable refrigerant R290/R600a used. To be repaired only by trained service personnel. Do not use mechanical devices to defrost refrigerator. Do not puncture refrigerant tubing.

ATTENTION: pour assurer la sécurité , la fiche d'alimentation doit être retirée avant le nettoyage. Toutes les précautions de sécurité doivent être respectées. Disposer correctement conformément aux réglementations fédérales ou locales. Risque d'incendie ou d'explosion dû à la perforation du tube réfrigérant. Suivre la manutention instructions soigneusement.

Danger: risque d'incendie ou d'explosion. Réfrigérant inflammable R290/R600a utilisé . Être réparé uniquement par un technicien qualifié .

N'utilisez pas de dispositifs mécaniques pour dégivrer le réfrigérateur. Ne pas perforer le tube réfrigérant.

Parts and features



- 22. Door
- 23. Handle Caster
- 24. Light
- 25. basket
- 26. Box feet
- 27. drain plug
- 28. Body

Technical parameter


Model	Rated voltage (V)	Rated frequency (Hz)	Rated Current: (W)
BD-95JEW	115~	60	1.2A
BD-95JEB			
BD-142JEW			
BD-142JEB			
BD-192JEW			1.4A
BD-192JEB			

How to Use

Allow to stand for a minimum of 4 hours before plugging in to the mains. The temperature is controlled by the temperature control knob located on the front face, at the bottom right hand side. Rotate the control knob left or right to regulate the temperature inside the freezer.

When initial operation, the freezer should run empty about one hour before storing food in it.

Before placing food into the freezer, adjust the temperature control to the lowest point (highest number) and let it run until the temperature of inner cabinet decreases to 0°Fahrenheit (-18°Celsius). Put the food in, and after 12 hours adjust the temperature control to the normal point.



- Initially set the temperature to 6.8°F(-14°C)
- Place food inside the chest freezer after using it for 24 hours.
- Set the chest freezer to your desired setting using ▲ and ▼ buttons
- Press both ▲ and ▼ buttons at the same time for 3 seconds to lock and unlock control panel.
- The chest freezer has two temperature ranges: -14°F(-26°C) to 6.8°F(-14°C) and 32°F (0°C) to 50°F(10°C). If you increase the temperature past 6.8°F(-14°C), it will automatically jump to 32°F (0°C).
- When the compressor works continuously for 24 hours, it will stop automatically for 20 minutes before restarting again.
- In case you unplug your chest freezer or experience an electrical outage the unit will start 5 minutes after it is plugged back in or power is recovered. This is to protect the compressor.

To activate Fast Freeze Mode: Press  and hold for 3 seconds. The compressor will run for 24 hours and will stop after that period of time or when the inside temperature drops to -18°F(-28°C). What is Fast Freeze Mode? Fast Freeze Mode reduces the time it takes to freeze large amounts of fresh, unfrozen food. The faster food is frozen, the better the quality will be when the food is thawed. When do you need to activate Fast Freeze Mode? Depending on how much food you plan on freezing at once, you may need to activate Fast Freeze Mode. If you plan on freezing food between 4-11lbs., we recommend you activate freeze mode as you load it in. For anything over 11lbs. We recommend you activate Fast Freeze Mode at least three hours before placing the food in the freezer. For smaller amounts of food (2 lbs. or under) it's not necessary to use Fast Freeze Mode, since any other temperature setting will be able to freeze your food fast enough while still maintaining its quality.

Indicator lights

“**Power**” indicates the freezer is switched on.

“**Run**” indicates the compressor is working.

Food Storage

- Do not fill the freezer full of products. You should leave space between items and the inner surface of the cabinet, so as to keep good ventilation of cold air and freeze evenly. Do not put in any bottled or canned beverage with freezing point above the temperature in the cabinet when it is below zero.
- For foods that should be moisture-free or lose water easily, wrap them up with hermetical food bags or fresh films before putting in the cabinet for the sake of avoiding smell-mixing and reducing frosting.
- Storage of volatile and combustible gases, liquids such as strong alkalies, strong acids, petrol ,etc. is forbidden.
- Never put hot food directly in the freezer. Food should be cold or frozen before placing it inside.
- The cabinet is intended exclusively for the storage and/or display of packaged foods only.

Maintenance

- The freezer should be cleaned regularly. When cleaning, turn off the power, take out the foods in the cabinet, clean the inside using water or a little neutral detergent.
- Do not use boiling water, acid, chemical diluent, petrol and oil, or dirt-removing powder.
- Dry it after cleaning.
- Use light soap water when cleaning the door seal, apply a little of talcum powder on it after natural drying to extend its service life.
- Use soft cloth with water or a little detergent to clean the out surface. Note, keeping the power supply and lower part of connect wires away from water to avoid electricity leakage.
- Except common breakdowns, those who are not service technician should not take apart and repair the freezer on their own so as to avoid worsening the trouble. Unauthorized repair of electrical part such as compressor, temperature controller is forbidden.
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available on hand. A dry chemical or CO2 fire extinguisher should be adjacent to the charging area.

- Notice: Any person who is involved with working on or breaking into a
- refrigerant circuit should hold a current valid certificate from an
- industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
- Notice: Servicing shall only be performed as recommended by the equipment
- manufacturer. Maintenance and repair requiring the assistance of other skilled
- personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment shall be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- Checking for presence of refrigerant, the area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e., non-sparking, adequately sealed, or intrinsically safe.
- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times, the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.
- Detection of flammable refrigerants: Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

Defrosting

Defrost for better freezing efficiency when the frost film in the cabinet is 5mm/ 1/5" thick.


When defrosting, turn off the power, take out the frozen foods, open the door for warming and melting. Use soft cloth to absorb water and clean it up.

Extract the water conduit and put in a water container

Do not use sharp metal tools such as steel brush to clean the frost film when defrosting so as to avoid evaporator damage.

Never use hairdryers, electrical heaters or other such electrical appliances for defrosting.

When defrosting has finished drain the water in the bottom of the freezer by removing the cap, as illustrated below.



There is a water conduit at the bottom of the freezer, when defrosting, extract the rubber cover, the defrosted water will drip into the hole and flow out.

NOTES: PLEASE KEEP THE RUBBER COVER SAFE DURING THE DEFROSTING AND PUT IT BACK AFTER THE DEFROSTING IS COMPLETE

Trouble Shooting

Breakdown	Case	Removal method
The indicator is not on. The compressor does not start.	The plug isn't connected to the socket really.	Replug it.
	no power	Connect the socket with power.

The indicator is on ,but the compressor doesn't work and buzzes only	The power voltage is <98V in North America or <187V in Europe.	Put a power-regulator more than 1000W power together.
The compressor stops a minute after start, and restart after a few minutes, and so repeatedly.	The power voltage is >132V in North America or <242V in Europe	
The compressor works normally, but the temperature in the cabinet lowers too slowly.	The door is opened too frequently.	Reduce open times.
	The food in the cabinet is too much, and placed improperly.	Place foods properly keep place between them for ventilation of cold air.
	The frost film is too thick.	Take out foods and defrost.
	The surface of the condenser is too dirty.	Stop and clean the condenser.
	The door seals badly.	Adjust the door seal.
The noise is too loud	The freezer is placed unstably.	Place it stably.
	The fixing of the freezer is loose.	Tighten the fixing.
	there s contact between pipes.	Separate them.

The following are not faults:

When the freezer is working or after stopping for a while, the refrigerant in the pipes is cycling and gives out " running water " sounds.

The surface temperature of the compressor may be up 70~80°C/ 158 ~ 176°F when it is working.

The back side of step freezer gives out heat.

In rainy season, the outer surface of the cabinet may have dew, which makes no defects on normal use. Just dry it with a piece of cloth.

Manufacturer: Zhejinag XingXing Refrigeration Co.,Ltd.

Address: No.1688 Baiyunshan South Rd,Hongjia,Jiaojiang,Taizhou City,Zhejiang Province,China

E-mail: support@vevor.com






Upgrade · The Home Creator Way

CHEST FREEZER

Model:BD95JEW BD95JEB BD142JEW

BD142JEB BD192JEW BD192JEB

**MODEL: BD95JEW/BD95JEB/BD142JEW/BD142JEB/BD192JEW
BD192JEB**



<Picture Only For Reference >

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

	Warning-To reduce the risk of injury, user must read instructions manual carefully.
	CORRECT DISPOSAL This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheeled bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices

Dear Consumers:

Thank you very much for purchasing our products. In order to ensure your safety and achieve the best out of this freezer, please read this instruction carefully.

- The products are commercial chest freezers. These products are intended solely for the storage and/or display of packaged products that are not potentially hazardous foods.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Please according to local regulations regarding disposal of the appliance for its flammable blowing gas. Before you scrap the appliance, please take off the doors to prevent children trapped.

- WARNING – Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- WARNING – Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer
- WARNING – Do not damage the refrigerant circuit.
- WARNING – Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance is intended to be used in household and similar applications such as, staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; Catering and similar non-retail applications.
- The appliance shall not be installed in public corridors or lobbies.
Please according to local regulations regarding disposal of the appliance for its flammable gas. Before you scrap the appliance, please take off the doors to prevent children trapped
- Warning: the appliance shall be installed in accordance with national wiring regulations
- The appliance is to be installed in accordance with the Safety Standard for Refrigeration Systems, ANSI/ASHRAE 15.
- Notice: Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- Notice: Component parts shall be replaced with like components so as to minimize the risk of possible ignition due to incorrect parts.
- The appliance is to be installed in accordance with the Safety
- WARNING: Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.
- Warning: The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation;
- Warning: The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater).

- **Warning:** The appliance shall be stored so as to prevent mechanical damage from occurring
- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges, or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.
- Before carrying out Decommissioning procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.
- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, **FLAMMABLE REFRIGERANTS**
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders

Details of Product

It uses quality, effective and hermetic compressor with broad range of starting voltage, suitable ambient temperature: not higher than 38°C/100°F, reasonable matching of the freezer system guarantees its powerful refrigerant ability and energy saving.

A good choice for storage of your variety of frozen food product. It is easy to lift up the lid to get your frozen food and close the lid to seal the freezer in.

Caution for Using

Unpack all packages before using the freezer. Don't bend it over more than 60° while moving it.

The freezer should be installed in the environment of good ventilation, Cool and dry and without corrosive gas. It should not be installed close to heat sources or directly under the sunlight. The space more than 10cm

between the wall of the front and the back of the freezer should be allowed. When installing, the wheels should be padded well so as to make the freezer be level and stable, or it will cause vibration and too much noise. If power is cut off, wait at least 5 minutes before turning on again to avoid damage to the compressor.

To save energy, the door should not be frequently opened for a long time. The surface and the inside of the freezer should be dry and clean. Long term moisture will cause the freezer rust slowly. (There will be some stains On the surface.)

Periodical cleaning is suggested for your reference. Generally, 30-45 days once is best. When cleaning, it is best to wipe the inside and the surface of the showcase with the soft cloth with neutral soap or detergent. Refrigerant class A3 per ANSI/ASHRAE 34

The maximum loading of each type of basket is 8kg.

Attention: To ensure safety, the power plug must be pulled out before cleaning. All safety precautions must be followed. Dispose of properly in accordance with Federal or local regulations. Risk of fire or explosion due to puncture of refrigerant tubing. Follow handling instructions carefully.


DANGER: Risk of fire or explosion. Flammable refrigerant R290/R600a used. To be repaired only by trained service personnel. Do not use mechanical devices to defrost refrigerator. Do not puncture refrigerant tubing.

ATTENTION: pour assurer la sécurité , la fiche d'alimentation doit être retirée avant le nettoyage. Toutes les précautions de sécurité doivent être respectées. Disposer correctement conformément aux réglementations fédérales ou locales. Risque d'incendie ou d'explosion dû à la perforation du tube réfrigérant. Suivre la manutention instructions soigneusement.

Danger: risque d'incendie ou d'explosion. Réfrigérant inflammable R290/R600a utilisé . Être réparé uniquement par un technicien qualifié .

N'utilisez pas de dispositifs mécaniques pour dégivrer le réfrigérateur. Ne pas perforer le tube réfrigérant.

Parts and features



Technical parameter


Model	Rated voltage (V)	Rated frequency (Hz)	Rated Current: (W)
BD-95JEW	115~	60	1.2A
BD-95JEB			
BD-142JEW			
BD-142JEB			
BD-192JEW			1.4A
BD-192JEB			

How to Use

Allow to stand for a minimum of 4 hours before plugging in to the mains. The temperature is controlled by the temperature control knob located on the front face, at the bottom right hand side. Rotate the control knob left or right to regulate the temperature inside the freezer.

When initial operation, the freezer should run empty about one hour before storing food in it.

Before placing food into the freezer, adjust the temperature control to the lowest point (highest number) and let it run until the temperature of inner cabinet decreases to 0°Fahrenheit (-18°Celsius). Put the food in, and after 12 hours adjust the temperature control to the normal point.



- Initially set the temperature to 6.8°F(-14°C)
- Place food inside the chest freezer after using it for 24 hours.
- Set the chest freezer to your desired setting using ▲ and ▼ buttons
- Press both ▲ and ▼ buttons at the same time for 3 seconds to lock and unlock control panel.
- The chest freezer has two temperature ranges: -14°F(-26°C) to 6.8°F(-14°C) and 32°F (0°C) to 50°F(10°C). If you increase the temperature past 6.8°F(-14°C), it will automatically jump to 32°F (0°C).
- When the compressor works continuously for 24 hours, it will stop automatically for 20 minutes before restarting again.
- In case you unplug your chest freezer or experience an electrical outage the unit will start 5 minutes after it is plugged back in or power is recovered. This is to protect the compressor.

To activate Fast Freeze Mode: Press  and hold for 3 seconds. The compressor will run for 24 hours and will stop after that period of time or when the inside temperature drops to -18°F(-28°C). What is Fast Freeze Mode? Fast Freeze Mode reduces the time it takes to freeze large amounts of fresh, unfrozen food. The faster food is frozen, the better the quality will be when the food is thawed. When do you need to activate Fast Freeze Mode? Depending on how much food you plan on freezing at once, you may need to activate Fast Freeze Mode. If you plan on freezing food between 4-11lbs., we recommend you activate freeze mode as you load it in. For anything over 11lbs. We recommend you activate Fast Freeze Mode at least three hours before placing the food in the freezer. For smaller amounts of food (2 lbs. or under) it's not necessary to use Fast Freeze Mode, since any other temperature setting will be able to freeze your food fast enough while still maintaining its quality.

Indicator lights

“**Power**” indicates the freezer is switched on.

“**Run**” indicates the compressor is working.

Food Storage

- Do not fill the freezer full of products. You should leave space between items and the inner surface of the cabinet, so as to keep good ventilation of cold air and freeze evenly. Do not put in any bottled or canned beverage with freezing point above the temperature in the cabinet when it is below zero.
- For foods that should be moisture-free or lose water easily, wrap them up with hermetical food bags or fresh films before putting in the cabinet for the sake of avoiding smell-mixing and reducing frosting.
- Storage of volatile and combustible gases, liquids such as strong alkalies, strong acids, petrol ,etc. is forbidden.
- Never put hot food directly in the freezer. Food should be cold or frozen before placing it inside.
- The cabinet is intended exclusively for the storage and/or display of packaged foods only.

Maintenance

- The freezer should be cleaned regularly. When cleaning, turn off the power, take out the foods in the cabinet, clean the inside using water or a little neutral detergent.
- Do not use boiling water, acid, chemical diluent, petrol and oil, or dirt-removing powder.
- Dry it after cleaning.
- Use light soap water when cleaning the door seal, apply a little of talcum powder on it after natural drying to extend its service life.
- Use soft cloth with water or a little detergent to clean the out surface. Note, keeping the power supply and lower part of connect wires away from water to avoid electricity leakage.
- Except common breakdowns, those who are not service technician should not take apart and repair the freezer on their own so as to avoid worsening the trouble. Unauthorized repair of electrical part such as compressor, temperature controller is forbidden.
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available on hand. A dry chemical or CO2 fire extinguisher should be adjacent to the charging area.

- Notice: Any person who is involved with working on or breaking into a
- refrigerant circuit should hold a current valid certificate from an
- industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
- Notice: Servicing shall only be performed as recommended by the equipment
- manufacturer. Maintenance and repair requiring the assistance of other skilled
- personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment shall be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- Checking for presence of refrigerant, the area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e., non-sparking, adequately sealed, or intrinsically safe.
- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times, the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.
- Detection of flammable refrigerants: Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

Defrosting

Defrost for better freezing efficiency when the frost film in the cabinet is 5mm/ 1/5" thick.


When defrosting, turn off the power, take out the frozen foods, open the door for warming and melting. Use soft cloth to absorb water and clean it up.

Extract the water conduit and put in a water container

Do not use sharp metal tools such as steel brush to clean the frost film when defrosting so as to avoid evaporator damage.

Never use hairdryers, electrical heaters or other such electrical appliances for defrosting.

When defrosting has finished drain the water in the bottom of the freezer by removing the cap, as illustrated below.



There is a water conduit at the bottom of the freezer, when defrosting, extract the rubber cover, the defrosted water will drip into the hole and flow out.

NOTES: PLEASE KEEP THE RUBBER COVER SAFE DURING THE DEFROSTING AND PUT IT BACK AFTER THE DEFROSTING IS COMPLETE

Trouble Shooting

Breakdown	Case	Removal method
The indicator is not on. The compressor does not start.	The plug isn't connected to the socket really.	Replug it.
	no power	Connect the socket with power.

The indicator is on ,but the compressor doesn't work and buzzes only	The power voltage is <98V in North America or <187V in Europe.	Put a power-regulator more than 1000W power together.
The compressor stops a minute after start, and restart after a few minutes, and so repeatedly.	The power voltage is >132V in North America or <242V in Europe	
The compressor works normally, but the temperature in the cabinet lowers too slowly.	The door is opened too frequently.	Reduce open times.
	The food in the cabinet is too much, and placed improperly.	Place foods properly keep place between them for ventilation of cold air.
	The frost film is too thick.	Take out foods and defrost.
	The surface of the condenser is too dirty.	Stop and clean the condenser.
	The door seals badly.	Adjust the door seal.
The noise is too loud	The freezer is placed unstably.	Place it stably.
	The fixing of the freezer is loose.	Tighten the fixing.
	there s contact between pipes.	Separate them.

The following are not faults:

When the freezer is working or after stopping for a while, the refrigerant in the pipes is cycling and gives out " running water " sounds.

The surface temperature of the compressor may be up 70~80°C/ 158 ~ 176°F when it is working.

The back side of step freezer gives out heat.

In rainy season, the outer surface of the cabinet may have dew, which makes no defects on normal use. Just dry it with a piece of cloth.

Manufacturer: Zhejinag XingXing Refrigeration Co.,Ltd.

Address: No.1688 Baiyunshan South Rd,Hongjia,Jiaojiang,Taizhou City,Zhejiang Province,China

E-mail: support@vevor.com






Upgrade · The Home Creator Way

CHEST FREEZER

Model:BD95JEW BD95JEB BD142JEW

BD142JEB BD192JEW BD192JEB

**MODEL: BD95JEW/BD95JEB/BD142JEW/BD142JEB/BD192JEW
BD192JEB**



<Picture Only For Reference >

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

	Warning-To reduce the risk of injury, user must read instructions manual carefully.
	CORRECT DISPOSAL This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheeled bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices

Dear Consumers:

Thank you very much for purchasing our products. In order to ensure your safety and achieve the best out of this freezer, please read this instruction carefully.

- The products are commercial chest freezers. These products are intended solely for the storage and/or display of packaged products that are not potentially hazardous foods.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Please according to local regulations regarding disposal of the appliance for its flammable blowing gas. Before you scrap the appliance, please take off the doors to prevent children trapped.

- WARNING – Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- WARNING – Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer
- WARNING – Do not damage the refrigerant circuit.
- WARNING – Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance is intended to be used in household and similar applications such as, staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; Catering and similar non-retail applications.
- The appliance shall not be installed in public corridors or lobbies.
Please according to local regulations regarding disposal of the appliance for its flammable gas. Before you scrap the appliance, please take off the doors to prevent children trapped
- Warning: the appliance shall be installed in accordance with national wiring regulations
- The appliance is to be installed in accordance with the Safety Standard for Refrigeration Systems, ANSI/ASHRAE 15.
- Notice: Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- Notice: Component parts shall be replaced with like components so as to minimize the risk of possible ignition due to incorrect parts.
- The appliance is to be installed in accordance with the Safety
- WARNING: Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.
- Warning: The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation;
- Warning: The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater).

- **Warning:** The appliance shall be stored so as to prevent mechanical damage from occurring
- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges, or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.
- Before carrying out Decommissioning procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.
- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, **FLAMMABLE REFRIGERANTS**
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders

Details of Product

It uses quality, effective and hermetic compressor with broad range of starting voltage, suitable ambient temperature: not higher than 38°C/100°F, reasonable matching of the freezer system guarantees its powerful refrigerant ability and energy saving.

A good choice for storage of your variety of frozen food product. It is easy to lift up the lid to get your frozen food and close the lid to seal the freezer in.

Caution for Using

Unpack all packages before using the freezer. Don't bend it over more than 60° while moving it.

The freezer should be installed in the environment of good ventilation, Cool and dry and without corrosive gas. It should not be installed close to heat sources or directly under the sunlight. The space more than 10cm

between the wall of the front and the back of the freezer should be allowed. When installing, the wheels should be padded well so as to make the freezer be level and stable, or it will cause vibration and too much noise. If power is cut off, wait at least 5 minutes before turning on again to avoid damage to the compressor.

To save energy, the door should not be frequently opened for a long time. The surface and the inside of the freezer should be dry and clean. Long term moisture will cause the freezer rust slowly. (There will be some stains On the surface.)

Periodical cleaning is suggested for your reference. Generally, 30-45 days once is best. When cleaning, it is best to wipe the inside and the surface of the showcase with the soft cloth with neutral soap or detergent. Refrigerant class A3 per ANSI/ASHRAE 34

The maximum loading of each type of basket is 8kg.

Attention: To ensure safety, the power plug must be pulled out before cleaning. All safety precautions must be followed. Dispose of properly in accordance with Federal or local regulations. Risk of fire or explosion due to puncture of refrigerant tubing. Follow handling instructions carefully.


DANGER: Risk of fire or explosion. Flammable refrigerant R290/R600a used. To be repaired only by trained service personnel. Do not use mechanical devices to defrost refrigerator. Do not puncture refrigerant tubing.

ATTENTION: pour assurer la sécurité , la fiche d'alimentation doit être retirée avant le nettoyage. Toutes les précautions de sécurité doivent être respectées. Disposer correctement conformément aux réglementations fédérales ou locales. Risque d'incendie ou d'explosion dû à la perforation du tube réfrigérant. Suivre la manutention instructions soigneusement.

Danger: risque d'incendie ou d'explosion. Réfrigérant inflammable R290/R600a utilisé . Être réparé uniquement par un technicien qualifié .

N'utilisez pas de dispositifs mécaniques pour dégivrer le réfrigérateur. Ne pas perforer le tube réfrigérant.

Parts and features



Technical parameter


Model	Rated voltage (V)	Rated frequency (Hz)	Rated Current: (W)
BD-95JEW	115~	60	1.2A
BD-95JEB			
BD-142JEW			
BD-142JEB			
BD-192JEW			1.4A
BD-192JEB			

How to Use

Allow to stand for a minimum of 4 hours before plugging in to the mains. The temperature is controlled by the temperature control knob located on the front face, at the bottom right hand side. Rotate the control knob left or right to regulate the temperature inside the freezer.

When initial operation, the freezer should run empty about one hour before storing food in it.

Before placing food into the freezer, adjust the temperature control to the lowest point (highest number) and let it run until the temperature of inner cabinet decreases to 0°Fahrenheit (-18°Celsius). Put the food in, and after 12 hours adjust the temperature control to the normal point.



- Initially set the temperature to 6.8°F(-14°C)
- Place food inside the chest freezer after using it for 24 hours.
- Set the chest freezer to your desired setting using ▲ and ▼ buttons
- Press both ▲ and ▼ buttons at the same time for 3 seconds to lock and unlock control panel.
- The chest freezer has two temperature ranges: -14°F(-26°C) to 6.8°F(-14°C) and 32°F (0°C) to 50°F(10°C). If you increase the temperature past 6.8°F(-14°C), it will automatically jump to 32°F (0°C).
- When the compressor works continuously for 24 hours, it will stop automatically for 20 minutes before restarting again.
- In case you unplug your chest freezer or experience an electrical outage the unit will start 5 minutes after it is plugged back in or power is recovered. This is to protect the compressor.

To activate Fast Freeze Mode: Press  and hold for 3 seconds. The compressor will run for 24 hours and will stop after that period of time or when the inside temperature drops to -18°F(-28°C). What is Fast Freeze Mode? Fast Freeze Mode reduces the time it takes to freeze large amounts of fresh, unfrozen food. The faster food is frozen, the better the quality will be when the food is thawed. When do you need to activate Fast Freeze Mode? Depending on how much food you plan on freezing at once, you may need to activate Fast Freeze Mode. If you plan on freezing food between 4-11lbs., we recommend you activate freeze mode as you load it in. For anything over 11lbs. We recommend you activate Fast Freeze Mode at least three hours before placing the food in the freezer. For smaller amounts of food (2 lbs. or under) it's not necessary to use Fast Freeze Mode, since any other temperature setting will be able to freeze your food fast enough while still maintaining its quality.

Indicator lights

“**Power**” indicates the freezer is switched on.

“**Run**” indicates the compressor is working.

Food Storage

- Do not fill the freezer full of products. You should leave space between items and the inner surface of the cabinet, so as to keep good ventilation of cold air and freeze evenly. Do not put in any bottled or canned beverage with freezing point above the temperature in the cabinet when it is below zero.
- For foods that should be moisture-free or lose water easily, wrap them up with hermetical food bags or fresh films before putting in the cabinet for the sake of avoiding smell-mixing and reducing frosting.
- Storage of volatile and combustible gases, liquids such as strong alkalies, strong acids, petrol ,etc. is forbidden.
- Never put hot food directly in the freezer. Food should be cold or frozen before placing it inside.
- The cabinet is intended exclusively for the storage and/or display of packaged foods only.

Maintenance

- The freezer should be cleaned regularly. When cleaning, turn off the power, take out the foods in the cabinet, clean the inside using water or a little neutral detergent.
- Do not use boiling water, acid, chemical diluent, petrol and oil, or dirt-removing powder.
- Dry it after cleaning.
- Use light soap water when cleaning the door seal, apply a little of talcum powder on it after natural drying to extend its service life.
- Use soft cloth with water or a little detergent to clean the out surface. Note, keeping the power supply and lower part of connect wires away from water to avoid electricity leakage.
- Except common breakdowns, those who are not service technician should not take apart and repair the freezer on their own so as to avoid worsening the trouble. Unauthorized repair of electrical part such as compressor, temperature controller is forbidden.
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available on hand. A dry chemical or CO2 fire extinguisher should be adjacent to the charging area.

- Notice: Any person who is involved with working on or breaking into a
- refrigerant circuit should hold a current valid certificate from an
- industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
- Notice: Servicing shall only be performed as recommended by the equipment
- manufacturer. Maintenance and repair requiring the assistance of other skilled
- personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment shall be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- Checking for presence of refrigerant, the area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e., non-sparking, adequately sealed, or intrinsically safe.
- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times, the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.
- Detection of flammable refrigerants: Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

Defrosting

Defrost for better freezing efficiency when the frost film in the cabinet is 5mm/ 1/5" thick.


When defrosting, turn off the power, take out the frozen foods, open the door for warming and melting. Use soft cloth to absorb water and clean it up.

Extract the water conduit and put in a water container

Do not use sharp metal tools such as steel brush to clean the frost film when defrosting so as to avoid evaporator damage.

Never use hairdryers, electrical heaters or other such electrical appliances for defrosting.

When defrosting has finished drain the water in the bottom of the freezer by removing the cap, as illustrated below.



There is a water conduit at the bottom of the freezer, when defrosting, extract the rubber cover, the defrosted water will drip into the hole and flow out.

NOTES: PLEASE KEEP THE RUBBER COVER SAFE DURING THE DEFROSTING AND PUT IT BACK AFTER THE DEFROSTING IS COMPLETE

Trouble Shooting

Breakdown	Case	Removal method
The indicator is not on. The compressor does not start.	The plug isn't connected to the socket really.	Replug it.
	no power	Connect the socket with power.

The indicator is on ,but the compressor doesn't work and buzzes only	The power voltage is <98V in North America or <187V in Europe.	Put a power-regulator more than 1000W power together.
The compressor stops a minute after start, and restart after a few minutes, and so repeatedly.	The power voltage is >132V in North America or <242V in Europe	
The compressor works normally, but the temperature in the cabinet lowers too slowly.	The door is opened too frequently.	Reduce open times.
	The food in the cabinet is too much, and placed improperly.	Place foods properly keep place between them for ventilation of cold air.
	The frost film is too thick.	Take out foods and defrost.
	The surface of the condenser is too dirty.	Stop and clean the condenser.
	The door seals badly.	Adjust the door seal.
The noise is too loud	The freezer is placed unstably.	Place it stably.
	The fixing of the freezer is loose.	Tighten the fixing.
	there s contact between pipes.	Separate them.

The following are not faults:

When the freezer is working or after stopping for a while, the refrigerant in the pipes is cycling and gives out " running water " sounds.

The surface temperature of the compressor may be up 70~80°C/ 158 ~ 176°F when it is working.

The back side of step freezer gives out heat.

In rainy season, the outer surface of the cabinet may have dew, which makes no defects on normal use. Just dry it with a piece of cloth.

Manufacturer: Zhejinag XingXing Refrigeration Co.,Ltd.

Address: No.1688 Baiyunshan South Rd,Hongjia,Jiaojiang,Taizhou City,Zhejiang Province,China

E-mail: support@vevor.com






Upgrade · The Home Creator Way

CHEST FREEZER

Model:BD95JEW BD95JEB BD142JEW

BD142JEB BD192JEW BD192JEB

**MODEL: BD95JEW/BD95JEB/BD142JEW/BD142JEB/BD192JEW
BD192JEB**



<Picture Only For Reference >

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

	Warning-To reduce the risk of injury, user must read instructions manual carefully.
	CORRECT DISPOSAL This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheeled bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices

Dear Consumers:

Thank you very much for purchasing our products. In order to ensure your safety and achieve the best out of this freezer, please read this instruction carefully.

- The products are commercial chest freezers. These products are intended solely for the storage and/or display of packaged products that are not potentially hazardous foods.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Please according to local regulations regarding disposal of the appliance for its flammable blowing gas. Before you scrap the appliance, please take off the doors to prevent children trapped.

- WARNING – Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- WARNING – Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer
- WARNING – Do not damage the refrigerant circuit.
- WARNING – Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance is intended to be used in household and similar applications such as, staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; Catering and similar non-retail applications.
- The appliance shall not be installed in public corridors or lobbies.
Please according to local regulations regarding disposal of the appliance for its flammable gas. Before you scrap the appliance, please take off the doors to prevent children trapped
- Warning: the appliance shall be installed in accordance with national wiring regulations
- The appliance is to be installed in accordance with the Safety Standard for Refrigeration Systems, ANSI/ASHRAE 15.
- Notice: Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- Notice: Component parts shall be replaced with like components so as to minimize the risk of possible ignition due to incorrect parts.
- The appliance is to be installed in accordance with the Safety
- WARNING: Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.
- Warning: The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation;
- Warning: The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater).

- **Warning:** The appliance shall be stored so as to prevent mechanical damage from occurring
- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges, or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.
- Before carrying out Decommissioning procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.
- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, **FLAMMABLE REFRIGERANTS**
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders

Details of Product

It uses quality, effective and hermetic compressor with broad range of starting voltage, suitable ambient temperature: not higher than 38°C/100°F, reasonable matching of the freezer system guarantees its powerful refrigerant ability and energy saving.

A good choice for storage of your variety of frozen food product. It is easy to lift up the lid to get your frozen food and close the lid to seal the freezer in.

Caution for Using

Unpack all packages before using the freezer. Don't bend it over more than 60° while moving it.

The freezer should be installed in the environment of good ventilation, Cool and dry and without corrosive gas. It should not be installed close to heat sources or directly under the sunlight. The space more than 10cm

between the wall of the front and the back of the freezer should be allowed. When installing, the wheels should be padded well so as to make the freezer be level and stable, or it will cause vibration and too much noise. If power is cut off, wait at least 5 minutes before turning on again to avoid damage to the compressor.

To save energy, the door should not be frequently opened for a long time. The surface and the inside of the freezer should be dry and clean. Long term moisture will cause the freezer rust slowly. (There will be some stains On the surface.)

Periodical cleaning is suggested for your reference. Generally, 30-45 days once is best. When cleaning, it is best to wipe the inside and the surface of the showcase with the soft cloth with neutral soap or detergent. Refrigerant class A3 per ANSI/ASHRAE 34

The maximum loading of each type of basket is 8kg.

Attention: To ensure safety, the power plug must be pulled out before cleaning. All safety precautions must be followed. Dispose of properly in accordance with Federal or local regulations. Risk of fire or explosion due to puncture of refrigerant tubing. Follow handling instructions carefully.


DANGER: Risk of fire or explosion. Flammable refrigerant R290/R600a used. To be repaired only by trained service personnel. Do not use mechanical devices to defrost refrigerator. Do not puncture refrigerant tubing.

ATTENTION: pour assurer la sécurité , la fiche d'alimentation doit être retirée avant le nettoyage. Toutes les précautions de sécurité doivent être respectées. Disposer correctement conformément aux réglementations fédérales ou locales. Risque d'incendie ou d'explosion dû à la perforation du tube réfrigérant. Suivre la manutention instructions soigneusement.

Danger: risque d'incendie ou d'explosion. Réfrigérant inflammable R290/R600a utilisé . Être réparé uniquement par un technicien qualifié .

N'utilisez pas de dispositifs mécaniques pour dégivrer le réfrigérateur. Ne pas perforer le tube réfrigérant.

Parts and features



Technical parameter


Model	Rated voltage (V)	Rated frequency (Hz)	Rated Current: (W)
BD-95JEW	115~	60	1.2A
BD-95JEB			
BD-142JEW			
BD-142JEB			
BD-192JEW			1.4A
BD-192JEB			

How to Use

Allow to stand for a minimum of 4 hours before plugging in to the mains. The temperature is controlled by the temperature control knob located on the front face, at the bottom right hand side. Rotate the control knob left or right to regulate the temperature inside the freezer.

When initial operation, the freezer should run empty about one hour before storing food in it.

Before placing food into the freezer, adjust the temperature control to the lowest point (highest number) and let it run until the temperature of inner cabinet decreases to 0°Fahrenheit (-18°Celsius). Put the food in, and after 12 hours adjust the temperature control to the normal point.



- Initially set the temperature to 6.8°F(-14°C)
- Place food inside the chest freezer after using it for 24 hours.
- Set the chest freezer to your desired setting using ▲ and ▼ buttons
- Press both ▲ and ▼ buttons at the same time for 3 seconds to lock and unlock control panel.
- The chest freezer has two temperature ranges: -14°F(-26°C) to 6.8°F(-14°C) and 32°F (0°C) to 50°F(10°C). If you increase the temperature past 6.8°F(-14°C), it will automatically jump to 32°F (0°C).
- When the compressor works continuously for 24 hours, it will stop automatically for 20 minutes before restarting again.
- In case you unplug your chest freezer or experience an electrical outage the unit will start 5 minutes after it is plugged back in or power is recovered. This is to protect the compressor.

To activate Fast Freeze Mode: Press  and hold for 3 seconds. The compressor will run for 24 hours and will stop after that period of time or when the inside temperature drops to -18°F(-28°C). What is Fast Freeze Mode? Fast Freeze Mode reduces the time it takes to freeze large amounts of fresh, unfrozen food. The faster food is frozen, the better the quality will be when the food is thawed. When do you need to activate Fast Freeze Mode? Depending on how much food you plan on freezing at once, you may need to activate Fast Freeze Mode. If you plan on freezing food between 4-11lbs., we recommend you activate freeze mode as you load it in. For anything over 11lbs. We recommend you activate Fast Freeze Mode at least three hours before placing the food in the freezer. For smaller amounts of food (2 lbs. or under) it's not necessary to use Fast Freeze Mode, since any other temperature setting will be able to freeze your food fast enough while still maintaining its quality.

Indicator lights

“**Power**” indicates the freezer is switched on.

“**Run**” indicates the compressor is working.

Food Storage

- Do not fill the freezer full of products. You should leave space between items and the inner surface of the cabinet, so as to keep good ventilation of cold air and freeze evenly. Do not put in any bottled or canned beverage with freezing point above the temperature in the cabinet when it is below zero.
- For foods that should be moisture-free or lose water easily, wrap them up with hermetical food bags or fresh films before putting in the cabinet for the sake of avoiding smell-mixing and reducing frosting.
- Storage of volatile and combustible gases, liquids such as strong alkalies, strong acids, petrol ,etc. is forbidden.
- Never put hot food directly in the freezer. Food should be cold or frozen before placing it inside.
- The cabinet is intended exclusively for the storage and/or display of packaged foods only.

Maintenance

- The freezer should be cleaned regularly. When cleaning, turn off the power, take out the foods in the cabinet, clean the inside using water or a little neutral detergent.
- Do not use boiling water, acid, chemical diluent, petrol and oil, or dirt-removing powder.
- Dry it after cleaning.
- Use light soap water when cleaning the door seal, apply a little of talcum powder on it after natural drying to extend its service life.
- Use soft cloth with water or a little detergent to clean the out surface. Note, keeping the power supply and lower part of connect wires away from water to avoid electricity leakage.
- Except common breakdowns, those who are not service technician should not take apart and repair the freezer on their own so as to avoid worsening the trouble. Unauthorized repair of electrical part such as compressor, temperature controller is forbidden.
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available on hand. A dry chemical or CO2 fire extinguisher should be adjacent to the charging area.

- Notice: Any person who is involved with working on or breaking into a
- refrigerant circuit should hold a current valid certificate from an
- industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
- Notice: Servicing shall only be performed as recommended by the equipment
- manufacturer. Maintenance and repair requiring the assistance of other skilled
- personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment shall be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- Checking for presence of refrigerant, the area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e., non-sparking, adequately sealed, or intrinsically safe.
- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times, the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.
- Detection of flammable refrigerants: Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

Defrosting

Defrost for better freezing efficiency when the frost film in the cabinet is 5mm/ 1/5" thick.


When defrosting, turn off the power, take out the frozen foods, open the door for warming and melting. Use soft cloth to absorb water and clean it up.

Extract the water conduit and put in a water container

Do not use sharp metal tools such as steel brush to clean the frost film when defrosting so as to avoid evaporator damage.

Never use hairdryers, electrical heaters or other such electrical appliances for defrosting.

When defrosting has finished drain the water in the bottom of the freezer by removing the cap, as illustrated below.



There is a water conduit at the bottom of the freezer, when defrosting, extract the rubber cover, the defrosted water will drip into the hole and flow out.

NOTES: PLEASE KEEP THE RUBBER COVER SAFE DURING THE DEFROSTING AND PUT IT BACK AFTER THE DEFROSTING IS COMPLETE

Trouble Shooting

Breakdown	Case	Removal method
The indicator is not on. The compressor does not start.	The plug isn't connected to the socket really.	Replug it.
	no power	Connect the socket with power.

The indicator is on ,but the compressor doesn't work and buzzes only	The power voltage is <98V in North America or <187V in Europe.	Put a power-regulator more than 1000W power together.
The compressor stops a minute after start, and restart after a few minutes, and so repeatedly.	The power voltage is >132V in North America or <242V in Europe	
The compressor works normally, but the temperature in the cabinet lowers too slowly.	The door is opened too frequently.	Reduce open times.
	The food in the cabinet is too much, and placed improperly.	Place foods properly keep place between them for ventilation of cold air.
	The frost film is too thick.	Take out foods and defrost.
	The surface of the condenser is too dirty.	Stop and clean the condenser.
	The door seals badly.	Adjust the door seal.
The noise is too loud	The freezer is placed unstably.	Place it stably.
	The fixing of the freezer is loose.	Tighten the fixing.
	there s contact between pipes.	Separate them.

The following are not faults:

When the freezer is working or after stopping for a while, the refrigerant in the pipes is cycling and gives out " running water " sounds.

The surface temperature of the compressor may be up 70~80°C/ 158 ~ 176°F when it is working.

The back side of step freezer gives out heat.

In rainy season, the outer surface of the cabinet may have dew, which makes no defects on normal use. Just dry it with a piece of cloth.

Manufacturer: Zhejinag XingXing Refrigeration Co.,Ltd.

Address: No.1688 Baiyunshan South Rd,Hongjia,Jiaojiang,Taizhou City,Zhejiang Province,China

E-mail: support@vevor.com






Upgrade · The Home Creator Way

CHEST FREEZER

Model:BD95JEW BD95JEB BD142JEW

BD142JEB BD192JEW BD192JEB

**MODEL: BD95JEW/BD95JEB/BD142JEW/BD142JEB/BD192JEW
BD192JEB**



<Picture Only For Reference >

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

	Warning-To reduce the risk of injury, user must read instructions manual carefully.
	CORRECT DISPOSAL This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheeled bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices

Dear Consumers:

Thank you very much for purchasing our products. In order to ensure your safety and achieve the best out of this freezer, please read this instruction carefully.

- The products are commercial chest freezers. These products are intended solely for the storage and/or display of packaged products that are not potentially hazardous foods.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Please according to local regulations regarding disposal of the appliance for its flammable blowing gas. Before you scrap the appliance, please take off the doors to prevent children trapped.

- WARNING – Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- WARNING – Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer
- WARNING – Do not damage the refrigerant circuit.
- WARNING – Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance is intended to be used in household and similar applications such as, staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; Catering and similar non-retail applications.
- The appliance shall not be installed in public corridors or lobbies.
Please according to local regulations regarding disposal of the appliance for its flammable gas. Before you scrap the appliance, please take off the doors to prevent children trapped
- Warning: the appliance shall be installed in accordance with national wiring regulations
- The appliance is to be installed in accordance with the Safety Standard for Refrigeration Systems, ANSI/ASHRAE 15.
- Notice: Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- Notice: Component parts shall be replaced with like components so as to minimize the risk of possible ignition due to incorrect parts.
- The appliance is to be installed in accordance with the Safety
- WARNING: Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.
- Warning: The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation;
- Warning: The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater).

- **Warning:** The appliance shall be stored so as to prevent mechanical damage from occurring
- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges, or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.
- Before carrying out Decommissioning procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.
- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, **FLAMMABLE REFRIGERANTS**
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders

Details of Product

It uses quality, effective and hermetic compressor with broad range of starting voltage, suitable ambient temperature: not higher than 38°C/100°F, reasonable matching of the freezer system guarantees its powerful refrigerant ability and energy saving.

A good choice for storage of your variety of frozen food product. It is easy to lift up the lid to get your frozen food and close the lid to seal the freezer in.

Caution for Using

Unpack all packages before using the freezer. Don't bend it over more than 60° while moving it.

The freezer should be installed in the environment of good ventilation, Cool and dry and without corrosive gas. It should not be installed close to heat sources or directly under the sunlight. The space more than 10cm

between the wall of the front and the back of the freezer should be allowed. When installing, the wheels should be padded well so as to make the freezer be level and stable, or it will cause vibration and too much noise. If power is cut off, wait at least 5 minutes before turning on again to avoid damage to the compressor.

To save energy, the door should not be frequently opened for a long time. The surface and the inside of the freezer should be dry and clean. Long term moisture will cause the freezer rust slowly. (There will be some stains On the surface.)

Periodical cleaning is suggested for your reference. Generally, 30-45 days once is best. When cleaning, it is best to wipe the inside and the surface of the showcase with the soft cloth with neutral soap or detergent. Refrigerant class A3 per ANSI/ASHRAE 34

The maximum loading of each type of basket is 8kg.

Attention: To ensure safety, the power plug must be pulled out before cleaning. All safety precautions must be followed. Dispose of properly in accordance with Federal or local regulations. Risk of fire or explosion due to puncture of refrigerant tubing. Follow handling instructions carefully.


DANGER: Risk of fire or explosion. Flammable refrigerant R290/R600a used. To be repaired only by trained service personnel. Do not use mechanical devices to defrost refrigerator. Do not puncture refrigerant tubing.

ATTENTION: pour assurer la sécurité , la fiche d'alimentation doit être retirée avant le nettoyage. Toutes les précautions de sécurité doivent être respectées. Disposer correctement conformément aux réglementations fédérales ou locales. Risque d'incendie ou d'explosion dû à la perforation du tube réfrigérant. Suivre la manutention instructions soigneusement.

Danger: risque d'incendie ou d'explosion. Réfrigérant inflammable R290/R600a utilisé . Être réparé uniquement par un technicien qualifié .

N'utilisez pas de dispositifs mécaniques pour dégivrer le réfrigérateur. Ne pas perforer le tube réfrigérant.

Parts and features



Technical parameter


Model	Rated voltage (V)	Rated frequency (Hz)	Rated Current: (W)
BD-95JEW	115~	60	1.2A
BD-95JEB			
BD-142JEW			
BD-142JEB			
BD-192JEW			1.4A
BD-192JEB			

How to Use

Allow to stand for a minimum of 4 hours before plugging in to the mains. The temperature is controlled by the temperature control knob located on the front face, at the bottom right hand side. Rotate the control knob left or right to regulate the temperature inside the freezer.

When initial operation, the freezer should run empty about one hour before storing food in it.

Before placing food into the freezer, adjust the temperature control to the lowest point (highest number) and let it run until the temperature of inner cabinet decreases to 0°Fahrenheit (-18°Celsius). Put the food in, and after 12 hours adjust the temperature control to the normal point.



- Initially set the temperature to 6.8°F(-14°C)
- Place food inside the chest freezer after using it for 24 hours.
- Set the chest freezer to your desired setting using ▲ and ▼ buttons
- Press both ▲ and ▼ buttons at the same time for 3 seconds to lock and unlock control panel.
- The chest freezer has two temperature ranges: -14°F(-26°C) to 6.8°F(-14°C) and 32°F (0°C) to 50°F(10°C). If you increase the temperature past 6.8°F(-14°C), it will automatically jump to 32°F (0°C).
- When the compressor works continuously for 24 hours, it will stop automatically for 20 minutes before restarting again.
- In case you unplug your chest freezer or experience an electrical outage the unit will start 5 minutes after it is plugged back in or power is recovered. This is to protect the compressor.

To activate Fast Freeze Mode: Press  and hold for 3 seconds. The compressor will run for 24 hours and will stop after that period of time or when the inside temperature drops to -18°F(-28°C). What is Fast Freeze Mode? Fast Freeze Mode reduces the time it takes to freeze large amounts of fresh, unfrozen food. The faster food is frozen, the better the quality will be when the food is thawed. When do you need to activate Fast Freeze Mode? Depending on how much food you plan on freezing at once, you may need to activate Fast Freeze Mode. If you plan on freezing food between 4-11lbs., we recommend you activate freeze mode as you load it in. For anything over 11lbs. We recommend you activate Fast Freeze Mode at least three hours before placing the food in the freezer. For smaller amounts of food (2 lbs. or under) it's not necessary to use Fast Freeze Mode, since any other temperature setting will be able to freeze your food fast enough while still maintaining its quality.

Indicator lights

“**Power**” indicates the freezer is switched on.

“**Run**” indicates the compressor is working.

Food Storage

- Do not fill the freezer full of products. You should leave space between items and the inner surface of the cabinet, so as to keep good ventilation of cold air and freeze evenly. Do not put in any bottled or canned beverage with freezing point above the temperature in the cabinet when it is below zero.
- For foods that should be moisture-free or lose water easily, wrap them up with hermetical food bags or fresh films before putting in the cabinet for the sake of avoiding smell-mixing and reducing frosting.
- Storage of volatile and combustible gases, liquids such as strong alkalies, strong acids, petrol ,etc. is forbidden.
- Never put hot food directly in the freezer. Food should be cold or frozen before placing it inside.
- The cabinet is intended exclusively for the storage and/or display of packaged foods only.

Maintenance

- The freezer should be cleaned regularly. When cleaning, turn off the power, take out the foods in the cabinet, clean the inside using water or a little neutral detergent.
- Do not use boiling water, acid, chemical diluent, petrol and oil, or dirt-removing powder.
- Dry it after cleaning.
- Use light soap water when cleaning the door seal, apply a little of talcum powder on it after natural drying to extend its service life.
- Use soft cloth with water or a little detergent to clean the out surface. Note, keeping the power supply and lower part of connect wires away from water to avoid electricity leakage.
- Except common breakdowns, those who are not service technician should not take apart and repair the freezer on their own so as to avoid worsening the trouble. Unauthorized repair of electrical part such as compressor, temperature controller is forbidden.
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available on hand. A dry chemical or CO2 fire extinguisher should be adjacent to the charging area.

- Notice: Any person who is involved with working on or breaking into a
- refrigerant circuit should hold a current valid certificate from an
- industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
- Notice: Servicing shall only be performed as recommended by the equipment
- manufacturer. Maintenance and repair requiring the assistance of other skilled
- personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment shall be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- Checking for presence of refrigerant, the area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e., non-sparking, adequately sealed, or intrinsically safe.
- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times, the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.
- Detection of flammable refrigerants: Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

Defrosting

Defrost for better freezing efficiency when the frost film in the cabinet is 5mm/ 1/5" thick.


When defrosting, turn off the power, take out the frozen foods, open the door for warming and melting. Use soft cloth to absorb water and clean it up.

Extract the water conduit and put in a water container

Do not use sharp metal tools such as steel brush to clean the frost film when defrosting so as to avoid evaporator damage.

Never use hairdryers, electrical heaters or other such electrical appliances for defrosting.

When defrosting has finished drain the water in the bottom of the freezer by removing the cap, as illustrated below.



There is a water conduit at the bottom of the freezer, when defrosting, extract the rubber cover, the defrosted water will drip into the hole and flow out.

NOTES: PLEASE KEEP THE RUBBER COVER SAFE DURING THE DEFROSTING AND PUT IT BACK AFTER THE DEFROSTING IS COMPLETE

Trouble Shooting

Breakdown	Case	Removal method
The indicator is not on. The compressor does not start.	The plug isn't connected to the socket really.	Replug it.
	no power	Connect the socket with power.

The indicator is on ,but the compressor doesn't work and buzzes only	The power voltage is <98V in North America or <187V in Europe.	Put a power-regulator more than 1000W power together.
The compressor stops a minute after start, and restart after a few minutes, and so repeatedly.	The power voltage is >132V in North America or <242V in Europe	
The compressor works normally, but the temperature in the cabinet lowers too slowly.	The door is opened too frequently.	Reduce open times.
	The food in the cabinet is too much, and placed improperly.	Place foods properly keep place between them for ventilation of cold air.
	The frost film is too thick.	Take out foods and defrost.
	The surface of the condenser is too dirty.	Stop and clean the condenser.
	The door seals badly.	Adjust the door seal.
The noise is too loud	The freezer is placed unstably.	Place it stably.
	The fixing of the freezer is loose.	Tighten the fixing.
	there s contact between pipes.	Separate them.

The following are not faults:

When the freezer is working or after stopping for a while, the refrigerant in the pipes is cycling and gives out " running water " sounds.

The surface temperature of the compressor may be up 70~80°C/ 158 ~ 176°F when it is working.

The back side of step freezer gives out heat.

In rainy season, the outer surface of the cabinet may have dew, which makes no defects on normal use. Just dry it with a piece of cloth.

Manufacturer: Zhejinag XingXing Refrigeration Co.,Ltd.

Address: No.1688 Baiyunshan South Rd,Hongjia,Jiaojiang,Taizhou City,Zhejiang Province,China

E-mail: support@vevor.com

